


Maintenance Minder™

Reminds you when indicated maintenance service is due.

When maintenance is due, the system message indicator comes on and a message appears on the driver information interface every time you turn the vehicle on. Press either Info button (◀/▶) on the steering wheel to change displays.



All maintenance services should be performed in accordance with the intervals indicated by the driver information interface.

■ Maintenance Minder Service Codes

These codes indicate what services are due on your vehicle.

CODE	Maintenance Items
0	<ul style="list-style-type: none">• Inspect front and rear brakes• Check expiration date for Temporary Tire Repair Kit• Inspect these items:<ul style="list-style-type: none">• Tie rod ends, steering gear box, and boots• Suspension components• Driveshaft boots• Brake hoses and lines (including ABS/VSA)• All fluid levels and condition of fluids• Stay RR, RR Subframe• Under body battery cover
1	⊗ Rotate tires
2	⊗ Replace dust and pollen filter* ¹
3	⊗ Replace transmission fluid* ²
7	⊗ Replace brake fluid* ³

*1: If you drive primarily in urban areas that have high concentrations of soot in the air from industry and from diesel-powered vehicles, replace the dust and pollen filter every 15,000 miles.

*2: Driving in mountainous areas at very low vehicle speeds results in higher transmission temperatures. This requires transmission fluid changes more frequently than recommended by the Maintenance Minder. If you regularly drive your vehicle under these conditions, have the transmission fluid changed every 31,250 miles.

*3: If a Maintenance Minder message does not appear more than 3 years after the display for item 7 is reset, change the brake fluid and replace air cleaner element every 3 years.