


Maintenance Minder™

Reminds you when indicated maintenance service is due.

When maintenance is due, the system message indicator comes on and a message appears on the driver information interface every time you turn the vehicle on.

1. Press the Display/Information button.
2. Press the ◀/▶ buttons to select the wrench icon and press enter.
3. Press and hold the Enter button for about 10 seconds to enter reset mode.
4. Press the ▲/▼ buttons to select the maintenance item to reset or select All Due Items (you may also select cancel to end the process).
5. Press the Enter button to reset the selected item and repeat step 4 to reset any other items.



All maintenance services should be performed in accordance with the intervals indicated by the driver information interface.

U.S. models

Maintenance, replacement, or repair of emissions control devices and systems may be done by any automotive repair establishment or individuals using parts that are certified to EPA standards.

According to state and federal regulations, failure to perform maintenance on the maintenance main items marked with # will not void your emissions warranties. However, all maintenance services should be performed in accordance with the intervals indicated by the display.

■ Maintenance Minder Service Codes

These codes indicate what services are due on your vehicle.

U.S. models

CODE	Maintenance Main Items
A	Replace engine oil* ¹ and oil filter
0	Inspect front and rear brakes Check expiration date for Temporary Tire Repair kit Inspect these items: <ul style="list-style-type: none"> • Tie rod ends, steering gearbox, and boots • Suspension components • Driveshaft boots • Brake hoses and lines (including ABS/VSA) • All fluid levels and condition of fluids • Exhaust system[#] • Fuel lines and connections[#] • Under body battery cover

*1: If a Maintenance Minder message does not appear more than 12 months after the display is reset, change the engine oil every year.

#: See information on maintenance and emissions warranty.

CODE	Maintenance Sub Items
1	Rotate tires
2	Replace dust and pollen filter* ²
3	Replace transmission fluid* ³
4	Replace spark plugs Inspect valve clearance
5	Replace engine coolant
7	Replace brake fluid* ⁴
8	Replace air cleaner element* ⁵

*2: If you drive primarily in urban areas that have high concentrations of soot in the air from industry and from diesel-powered vehicles, replace the dust and pollen filter every 15,000 miles (24,000 km).

*3: Driving in mountainous areas at very low vehicle speeds results in higher transmission temperatures. This requires transmission fluid changes more frequently than recommended by the Maintenance Minder. If you regularly drive your vehicle under these conditions, have the transmission fluid changed every 47,500 miles (75,000 km) or 3 years.

*4: If a Maintenance Minder message does not appear more than 36 months after the display for item 7 is reset, change the brake fluid every 3 years.

*5: If you drive in dusty conditions, replace the air cleaner element every 15,000 miles (24,000 km).

In addition:

- Adjust the valves during services A, 0, 1, 2, or 3 if they are noisy.

Canadian models

CODE	Maintenance Main Items
A	Replace engine oil* ¹ and oil filter

*1: If a Maintenance Minder message does not appear more than 12 months after the display is reset, change the engine oil every year.

CODE	Maintenance Sub Items
1	Rotate tires
2	Replace dust and pollen filter* ²
3	Replace transmission fluid* ³
4	Replace spark plugs Inspect valve clearance
5	Replace engine coolant
7	Replace brake fluid* ⁴
8	Replace air cleaner element* ⁵
9	Service front and rear brakes Check expiration date for Temporary Tire Repair kit Inspect these items: <ul style="list-style-type: none"> • Tie rod ends, steering gearbox, and boots • Suspension components • Driveshaft boots • Brake hoses and lines (including ABS/VSA) • All fluid levels and condition of fluids • Exhaust system[#] • Fuel lines and connections[#] • Under body battery cover

*2: If you drive primarily in urban areas that have high concentrations of soot in the air from industry and from diesel-powered vehicles, replace the dust and pollen filter every 24,000 km (15,000 miles).

*3: Driving in mountainous areas at very low vehicle speeds results in higher transmission temperatures. This requires transmission fluid changes more frequently than recommended by the Maintenance Minder. If you regularly drive your vehicle under these conditions, have the transmission fluid changed every 96,000 km (60,000 miles) or 3 years.

*4: If a Maintenance Minder message does not appear more than 36 months after the display for item 7 is reset, change the brake fluid every 3 years.

*5: If you drive in dusty conditions, replace the air cleaner element every 24,000 km (15,000 miles).

#: See information on maintenance and emissions warranty.

In addition:

- Adjust the valves during services A, 1, 2, 3 or 9 if they are noisy.