


## Maintenance Minder™

When maintenance is due, the system message indicator comes on and a message appears on the display every time you turn the vehicle on. The messages notify you when to change the engine oil, or when to bring your vehicle to a dealer for indicated maintenance services.



Press the Select/reset knob (models with information display) or the steering-wheel buttons (models with multi-information display) to change displays.

- Independent of the Maintenance Minder information, replace the brake fluid every 3 years.
- Independent of the Maintenance Minder information, adjust the valves during services A, B, 1, 2, or 3 if they are noisy.

U.S. models

**Maintenance, replacement, or repair of emissions control devices and systems may be done by any automotive repair establishment or individuals using parts that are certified to EPA standards.**

According to state and federal regulations, failure to perform maintenance on the maintenance main items marked with # will not void your emissions warranties. However, all maintenance services should be performed in accordance with the intervals indicated by the multi-information display.

### ■ Maintenance Minder Service Codes

These codes indicate what services are due on your vehicle.

## MAINTENANCE

---

CODE	Maintenance Main Items
A	<ul style="list-style-type: none"><li>· Replace engine oil*<sup>1</sup></li></ul>
B	<ul style="list-style-type: none"><li>· Replace engine oil*<sup>1</sup> and oil filter</li><li>· Inspect front and rear brakes</li><li>· Check parking brake adjustment</li><li>· Inspect tie rod ends, steering gearbox, and boots</li><li>· Inspect suspension components</li><li>· Inspect driveshaft boots</li><li>· Inspect brake hoses and lines (Including ABS/VSA®)</li><li>· Inspect all fluid levels and condition of fluids</li><li>· Inspect exhaust system#</li><li>· Inspect fuel lines and connections #</li></ul>

\*1: If a message Maintenance does not appear more than 12 months after the display is reset, change the engine oil every year.

# : See information on maintenance and emissions warranty.

CODE	Maintenance Sub Items
1	<ul style="list-style-type: none"><li>· Rotate tires</li></ul>
2	<ul style="list-style-type: none"><li>· Replace air cleaner element*<sup>2</sup></li><li>· Replace dust and pollen filter*<sup>3</sup></li><li>· Inspect drive belt</li></ul>
3	<ul style="list-style-type: none"><li>· Replace transmission fluid</li></ul>
4	<ul style="list-style-type: none"><li>· Replace spark plugs</li><li>· Inspect valve clearance</li></ul>
5	<ul style="list-style-type: none"><li>· Replace engine coolant</li></ul>

\*2: If you drive in dusty conditions, replace the air cleaner element every 15,000 miles (24,000 km).

\*3: If you drive primarily in urban areas that have high concentrations of soot in the air from industry and from diesel-powered vehicles, replace the dust and pollen filter every 15,000 miles (24,000 km).