Models with 9-in. Color Touchscreen ➲P. 280

For navigation system operation ➲ See the Navigation System Manual

Audio/Information Screen

(Home) Button

(Back) Button

VOL/⏻ AUDIO
(Volume/Power) Knob

◄◄ (Seek/Track) Button

►►◄ (Seek/Track) Button