DRIVING POSITION MEMORY SYSTEM (DPMS) (if equipped)

Store a driver's seat and mirror position into memory for each remote transmitter.

Programming DPMS

1. **Turn** the vehicle on. **Shift** into Park (P).

2. **Adjust** your preferred seat and outside mirror settings.

3. **Press and hold** the SET button until you hear a beep, then release.

4. **Press and hold** the memory button # corresponding to the remote (1 or 2) you are using until you hear two beeps.

Note: A stored memory position is linked to the corresponding keyless remote (1 or 2). Each item begins to adjust when you unlock the driver's door with the remote and enter the vehicle.