BLUETOOTH® HANDSFREELINK® (HFL)

Place and receive phone calls through your vehicle's audio system. Visit *handsfreelink.honda.com* to check if your phone is compatible.

To reduce the potential for driver distraction, certain manual and touch screen functions may be inoperable or grayed out while the vehicle is moving. Voice commands are always available.

How to Use HFL



Pick-Up button: Answer an incoming call, or go directly to the Phone screen.

Talk button: Give HFL commands.

Back button: Cancel a command and return to the previous screen.

Hang-Up: End a call or decline a call.

Pairing Your Phone

Use this pairing method when no phone has ever been paired to the system. You can pair your compatible phone only when the vehicle is stopped.

Press and release the Talk button before you say a command.

1. **Press** the Pick-Up button to go to the Phone screen. A prompt appears. **Say** *"Yes."*

2. Make sure your phone is in discovery mode, and **say** *"OK."*

3. HFL searches for your phone. **Say** the number next to the phone when it appears on the list.

If your phone does not appear:
Say *"Find Another Phone"* and **search** for a HandsFreeLink device from your phone. **Connect** to HFL.

4. HFL gives you a four-digit code. **Enter** it on your phone when prompted. The phone is now paired.

Pairing Your Phone (continued)

Use this pairing method when a phone has already been paired to the system, or when you want to pair an additional phone.

Press and release the Talk button before you say a command.

1. **Press** the Pick-Up button to go to the Phone screen.

If a prompt appears asking to connect to a phone, **say** *"No"* and go to step 2.

2. **Say** *"Phone setup."*

3. **Say** *"Add a phone."*

4. **Say** *"Search."*

5. Make sure your phone is in discovery mode, and **say** *"OK."*

6. HFL searches for your phone. **Say** the number next to the phone when it appears on the list.

If your phone does not appear:
Say *"Find Another Phone"* and **search** for HandsFreeLink from your phone. **Connect** to HFL.

7. HFL gives you a four-digit code. **Enter** it on your phone when prompted. The phone is now paired.

Dialing a Number

Enter a 10-digit phone number to call.

Press and release the Talk button before you say a command.

1. **Press** the Pick-Up button to go to the Phone screen.

2. **Say** *"Dial."*

3. **Say** the entire phone number, then **say** *"Dial"* to call.

4. The call is connected and heard through the vehicle speakers.

Receiving a Call

A notification is heard and the following screen appears:



Press the Pick-Up button to accept the call.

Press the Hang-Up button to end or decline the call.

Using the Phonebook

When your phone is paired, its entire phonebook is automatically imported to the system.

Press and release the Talk button before you say a command.

1. **Press** the Pick-Up button to go to the Phone screen.

2. **Say** *"Phonebook."*

3. **Scroll** through the list to find the name and number you want to call. **Say** *"Dial,"* or **press** the Pick-Up button to call.

4. The call is connected and heard through the vehicle speakers.

Using Speed Dial

Store up to 15 numbers for quick calling. See your Navigation Manual for instructions on storing voice tags.

Press and release the Talk button before you say a command.

1. **Press** the Pick-Up button to go to the Phone screen.

2. **Say** *"Speed Dial 1"* (or *"Speed Dial 2"*) and the number next to the entry. For example, *"One."* **Say** *"Call,"* or **press** the Pick-Up button to call.

If an entry has a stored voice tag, **say** *"Dial by voice tag,"* followed by the voice tag name and *"Dial"* from any screen.

3. The call is connected and heard through the vehicle speakers.

Driver Distraction

To reduce the potential for driver distraction, certain functions may be inoperable or grayed out while the vehicle is moving. You may have to use voice commands, stop or pull over to perform the function.

The chart below shows a list of some operations that are restricted while the vehicle is moving.

Function	Restriction Level While Driving
HFL System (Without Navigation)	
10-key dial	Restricted
Phonebook	Restricted
Speed dial	Not restricted
Speed dial setup	Restricted
Call history	Not restricted
Call history scroll	Not restricted
Redial	Not restricted
Connect to a new phone	Restricted
Connect to a previously paired phone	Not restricted
Manual dial tones	Restricted
Read text	Restricted
Reply to text	Not restricted
HFL System (With Navigation)	
10-key dial	Voice command only
Phonebook	Voice command only. Limited to three screens
Speed dial	Not restricted
Speed dial setup	Restricted
Call history	Not restricted
Call history scroll	Voice command only. Limited to three screens
Redial	Not restricted
Connect to new phone	Restricted