TIRE PRESSURE MONITORING SYSTEM (TPMS)

Monitors the vehicle's tire pressures.

How It Works



Each tire valve stem contains a TPMS sensor.

When the tire pressure drops significantly below recommended levels, the low tire pressure indicator comes on.

If the TPMS indicator appears, there may be a problem with the system. See your dealer.

What to Do

1. **Visually inspect** the tires for damage.
2. **Use** a tire air pressure gauge to check which tire(s) have low pressure.

3. **Inflate** the tire(s), if necessary, to the recommended pressures listed on the label on the driver's doorjamb.