BLUETOOTH® HANDSFREELINK® (HFL)

Make and receive phone calls through your vehicle's audio system. Visit *handsfreelink.honda.com* to check if this feature is compatible with your phone.

How to Use HFL

Pick-Up button: Answer an incoming call, or go directly to the Phone screen.

Talk button: Give HFL commands.

Back button: Cancel a command and return to the previous screen.

Hang-Up button: End a call or decline a call.

CANCEL button: Cancel an operation or return to the previous screen.

PHONE button: Go directly to the phone screen.

Interface dial: Rotate or move up/down/left/right to scroll through selections. Press ENTER to make a selection.

Pairing Your Phone

Use this pairing method when no phone has ever been paired to the system. You can pair your compatible phone only when the vehicle is stopped.

Press and release the Talk button before you say a command.

1. Press PHONE to go to the Phone screen. A prompt appears. Say *"Yes."*
2. Make sure your phone is in discovery mode, and say *"OK."*
3. HFL searches for your phone. Say the number next to the phone when it appears on the list.

   If your phone does not appear:

   Say "Phone Not Found!" and search for a HandsFreeLink device from your phone. Connect to HFL.
4. HFL gives you a four-digit code. Enter it on your phone when prompted. The phone is now paired.

Use this pairing method when a phone has already been paired to the system, or when you want to pair an additional phone.

Press and release the Talk button before you say a command.

1. Press PHONE to go to the Phone screen. If a prompt appears asking to connect to a phone, say *"No."*
2. Say *"Phone setup."*
3. Say *"Connection."*
4. Say *"Add New Phone."*
5. Say the number of the location (1-6) to add the phone.
6. Make sure your phone is in discovery mode, and say *"OK."*
7. HFL searches for your phone. Say the number next to the phone when it appears on the list.

   If your phone does not appear:

   Say "Phone Not Found!" and search for a HandsFreeLink device from your phone. Connect to HFL.
8. HFL gives you a four-digit code. Enter it on your phone when prompted. The phone is now paired.

Making a Call

Dialing a Number

Press and release the Talk button before you say a command.

1. Press PHONE to go to the Phone screen.
2. Say *"Dial."*
3. Say the entire phone number.
4. Say *"Dial"* to begin the call.

Using the Imported Phonebook*

When your phone is paired, its entire phonebook is automatically imported to the system.

Press and release the Talk button before you say a command.

1. Press PHONE to go to the Phone screen.
2. Say *"Phonebook."*
3. Scroll through the list to find the name you want to call.
4. Say the number of the entry to begin the call.

** Visit handsfreelink.honda.com to check if this feature is available on your phone.*

Using Call History

View dialed, received, or missed calls from your phone.

Press and release the Talk button before you say a command.

1. Press PHONE to go to the Phone screen.
2. Say *"Call history."*
3. Scroll through the list to find the name or number you want to call.
4. Say the number next to the entry to begin the call.

Making a Call (continued)

Using Speed Dial and Voice Tags

Press and release the Talk button before you say a command.

1. Press PHONE to go to the Phone screen.
2. Say the number next to one of the first four entries to begin the call. For example, *"One."*

   For the complete list of speed dial entries, say *"More speed dial."*

   If an entry has a stored voice tag, say *"Dial by voice tag,"* followed by the voice tag name and *"Dial"* from any screen.

   Note: See your Owner's Manual for instructions on storing speed dial entries and voice tags.



Receiving a Call

A notification is heard and the following screen appears:

Press the Pick-Up button to accept the call.

Press the Hang-Up button to end or decline the call.



Driver Distraction

To reduce the potential for driver distraction, certain functions may be inoperable or grayed out while the vehicle is moving. You may have to use voice commands, stop or pull over to perform the function.

The chart below shows a list of some operations that are restricted while the vehicle is moving.

Function	Restriction Level While Driving
HFL System (Without Navigation)	
10-key dial	Restricted
Phonebook	Restricted
Speed dial	Not restricted
Speed dial setup	Restricted
Call history	Not restricted
Call history scroll	Not restricted
Redial	Not restricted
Connect to a new phone	Restricted
Connect to a previously paired phone	Not restricted
Manual dial tones	Restricted
Read text	Restricted
Reply to text	Not restricted
HFL System (With Navigation)	
10-key dial	Voice command only
Phonebook	Voice command only. Limited to three screens
Speed dial	Not restricted
Speed dial setup	Restricted
Call history	Not restricted
Call history scroll	Voice command only. Limited to three screens
Redial	Not restricted
Connect to new phone	Restricted