Climate Control System

Maintains your preferred interior temperature by selecting the proper mix of heated or cooled air and fan speed. Use the buttons on the dashboard to control the system.

Selected temperature display



A/C: Turn air conditioning and Plasmacluster on or off.

MODE: Select airflow location.

CLIMATE button: Select climate options on the touchscreen.

Driver's temperature control dial

Fan control buttons

Plasmacluster* Mark

Passenger's temperature control dial

AUTO button: Press, then use the temperature control dial to set your preferred temperature.

ON/OFF button

Defroster buttons

SYNC button: Set the passenger's side temperature to the same as the driver's side.

Recirculation buttons:
Recirculation mode (indicator on): Recirculates air from the vehicle's interior.
Auto mode (indicator on): Automatically switch between the recirculation and fresh air modes most suitable to environmental conditions.
Fresh air mode (both indicators off): Maintains outside ventilation. Keep the system in fresh air mode in normal situations.

*Plasmacluster is an ion-based air purification technology. Trademark of Sharp Corporation.