
BASIC AUDIO OPERATION

Operate basic controls of your audio system using various and convenient methods.

Steering Wheel Controls



Touchscreen Controls

Select various controls depending on the audio source being played.



Skip/Seek: Change stations, tracks, etc.

More: Select menu options and sound settings.

FM screen shown

USB Connection





or a USB flash drive to the USB port in the front console. Connect your device only when


your vehicle is stopped.

iPod® OR USB FLASH DRIVE

Play audio files from your compatible iPod or USB flash drive through your vehicle's audio system.

Playing Audio Files





iPod is a trademark of Apple, Inc.

- 2. Select Source and select the iPod or USB icon. 3. Use the touchscreen or steering wheel controls to change tracks.

- I. Press MENU. Use the selector knob to
- 4. Select a track to begin playing.

2. Select Music Search.

Searching for Music

make and enter selections.

3. Select a category or folder.




Play stored or streaming audio from your compatible phone through your vehicle's audio

system. Visit handsfreelink.honda.com to check if this feature is compatible with your phone.

BLUETOOTH & AUDIO


Playing Bluetooth Audio



Select the

Bluetooth icon

from Source.



- I. Make sure your phone is on and paired to Bluetooth® HandsFreeLink®"
 - Sound is redirected to the audio system. Make sure the volume on your phone
- is properly adjusted. 4. Use the touchscreen or steering wheel controls to change tracks.

- **Notes:** You may need to enable additional Bluetooth settings on your phone for
- playback.
- The play/pause function and remote audio controls are not supported on all phones.

Operate your phone only when your vehicle is stopped.