## HOMELINK®

The HomeLink Universal Transceiver can be programmed to operate up to three remote-controlled devices around your home, such as garage doors, lighting, or home security systems.

## Training a Button





- Position the remote transmitter you wish to link 1–3 inches from the HomeLink button you want to program.
  - Press and hold the desired HomeLink button and the button on the remote transmitter.

Does the HomeLink indicator (LED) blink at a faster rate after about 10 seconds?

a Press and hold the button on the remote and the HomeLink button at the same time. Then, while

Does the LED blink at a faster rate within 20 seconds?

button, press and release the button

continuing to hold the HomeLink

on the remote every 2 seconds.

NO YES

Press and hold the programmed HomeLink button for about a second.

Does the device (garage door opener) work?

NO

Press and hold the HomeLink button again.

Training complete

HomeLink indicator HomeLink LED flashes for 2 seconds, remains on.

- The remote has a rolling code. Press the "learn" button on the remote-controlled device (e.g., garage door opener).
- b Within 30 seconds, press and hold the programmed HomeLink button for 2 seconds.
- Press the programmed HomeLink button again; the remote-controlled device should operate.

If you have any problems programming HomeLink, see the owner's manual included with the device you are trying to program, call HomeLink at (800) 355-3515, or visit www.homelink.com.