
## **Audio Input**

## Auxiliary Input Jack, USB Adapter Cable\*

The auxiliary input jack, located inside the front console compartment, will accept input from standard audio accessories. Models with navigation include a USB adapter cable, also located inside the console compartment, for use with an iPod® or USB flash memory device.

To use the input jack or the USB adapter cable, connect a compatible audio unit to the jack or adapter cable, and press the AUX or CD/AUX button.



**Note**: A 1/8" mini-plug for the input jack and/or the dock connector cable for the iPod/ USB flash memory device are required.