

Navigation (if equipped)

Entering a Destination Using Voice Commands

Press and release the NAVI Talk button before you give a command.

1 Say "Display menu."

2 Say "Address."

3 Say "City" (or "Change state" if necessary).

4 Say the name of the city you want, or say "Current city" to select the city currently shown.


5 A list of city names appears. Say the number listed next to the city you want to select.

6 Say the street name. Do not include the direction (N, S, E, W) or type (St., Ave., Blvd., etc.).

7 A list of street names appears. Say the number listed next to the street you want to select.

8 Say the entire street address number. For example, "1-2-5-0."

9 The system calculates the route and displays the "Calculate route to" screen. Say "OK" to set the route.



Note: Entering destinations can also be done manually with the Interface Dial from the Menu screen.

Entering a Destination Using the “Find Nearest” Command


Try these simple steps to find a nearby point of interest, such as a gas station, movie theater, or restaurant.

Press and release the NAVI Talk button before you give a command.


1. Say “Find nearest ATM.”




2. A list of the nearest ATMs are displayed by shortest distance to destination.



3. Say the number you want to select.



4. The system calculates the route and displays the “Calculate route to” screen.
Say “OK” to set the route.



Commonly Used Voice Commands

Here are some examples of commonly used voice commands. Try some of these to familiarize yourself with the voice command system.

Press and release the NAVI Talk button before you give a command.


Look for Restaurants in Your Location

Say a command like “Display restaurants” to see restaurant icons appear on the map.



Make Audio Selections

Say a command like “Radio 97.1 FM” or “CD play track 5” to select that station or song.




Adjust the Vehicle's Climate Setting

Say a command like “Air conditioner on” and “Fan speed 4” to adjust the setting to your preference.



Get Estimated Distance to Destination

After a destination is entered, **say** “How far to destination?” to hear the remaining distance.



Commonly Used Voice Commands (continued)

Press and release the NAVI Talk button before you give a command.

General Commands


(Accepted on most screens to change displays)



- Display map
- Display menu
- Setup
- Information
- Display audio screen
- What time is it?

Find Place Commands

(Accepted on Map screen)



- Find nearest:
 - ATM
 - gas station
 - Mexican restaurant
 - post office
 - bank
 - Honda dealer
 - airport
 - hospital

Navigation Commands

(Accepted on Map screen after a destination is entered)



- How long/far to the destination?
- Display destination
- Display entire route

Display Commands

(Accepted on Map screen)



- Display (or hide):
 - ATM
 - gas station
 - restaurant
 - post office
- Display north up/heading up
- Zoom in/out
- Go home
- Display current location

Commonly Used Voice Commands (continued)

Press and release the NAVI Talk button before you give a command.

Audio Commands

(Accepted on most screens)



- Radio on
- Radio # FM/AM
- Radio preset 1/2/3/4/5/6
- XM channel #
- XM preset 1/2/3/4/5/6
- CD play
- CD play track/disc #
- CD skip forward/back
- Auxiliary (AUX) play

Setup Commands

(Accepted on the Setup screen)



- Brightness up/down
- Volume up/down/min/max/off
- Interface dial feedback on/off
- Guidance prompts min/max/normal

Climate Control Commands


(Accepted on most screens)



- Air conditioner on/off
- Rear defrost on/off
- Climate control recirculate/fresh air
- Fan speed up/down
- Temperature # degrees (# = 57–87)
- Temperature max hot/cold

Help Commands

(Accepted on most screens)



- Help (list of available commands for current screen)
- Voice command help (list of all available navigation, audio, and climate control commands)

Voice Command/
HFL/Navigation