

Eco Assist™/Auto Idle
Stop/Charge Assist

Ecological Drive Assist System (Eco Assist™)

The system monitors your driving style, then provides real-time feedback you can use to develop a style that maximizes fuel economy. It is always on and consists of the: ECO Guide (in the MID), Ambient Meter, ECON Mode button, and the ECON indicator.

ECON On Mode


Helps you further maximize your fuel economy by modifying some vehicle function.

To use **ECON On Mode**:

1. Press the **ECON** Button.



2. The **ECON** Mode Indicator Illuminates.





3. Check the MID.



4. Press the Info Button and toggle to the **Eco Guide** Feedback Monitor.



Driver Feedback



Real-time Fuel Efficiency Coach


Driving Style	Eco Drive Bar (In the MID)	Ambient Meter Background Color Changes	Fuel Efficiency
Smooth, steady acceleration maximizes fuel efficiency			High Low
Smooth, steady deceleration maximizes fuel efficiency			
Moderate acceleration			
Moderate deceleration			
Rapid acceleration lowers fuel efficiency			
Rapid deceleration lowers fuel efficiency			
Goals: • Keep the Eco Drive bar near the center. • Keep the Ambient Meter at GREEN. • Develop a driving style that maximizes fuel efficiency.			

Check your owner's manual for more information and instructions.

ECO Assist Scoring

Eco Assist scoring monitors the fuel efficiency of your driving style in real time and converts results into leaves, which are displayed on a series of five "plant" icons on the MID screen.

Start your vehicle.



Make sure the MID shows the **Eco Guide** Monitor on the display to view your Eco Assist score in real time.



As you drive, you will earn leaves if you drive in a fuel efficient manner, and lose them if you drive inefficiently.



When you turn the ignition off, your drive cycle and lifetime score are displayed on the MID.

Stage 1



Each time you reach a new stage, a Stage

Stage 2



Up Recognition icon will briefly appear on the MID. When you

Stage 3



reach the highest ranking, a Trophy icon will briefly appear.

Auto Idle Stop

Under certain conditions, the Auto Idle Stop system will shut the engine off at a stop in order to maximize fuel efficiency.



While driving, the engine is ON.



While at a stop, with the brake pedal pressed, the engine turns OFF.



As soon as you take your foot off the brake pedal, the engine turns back ON.

Note: The Auto Idle Stop will not function if you come to a stop while driving with the transmission in a position other than "D".

IMA Charge/Assist Gauge

This gauge shows the status of the Integrated Motor Assist (IMA).

The gauge shows you when the IMA battery is assisting the engine or charging.

Note: The IMA may not operate all the time if it is extremely hot or cold outside.



Check your owner's manual for additional information and instructions.

Eco Assist™/Auto Idle
Stop/Charge Assist