# Press and release the NAVI TALK button before giving each command.

- Say "Display menu."
- 2 Sav "Address."
- 3 Say "City" (or "Change state" if necessary).
- Say the name of the city you want, or say "Current city" to select the city currently shown.
- A list of city names will appear. Say the number listed next to the city you want to select.
- Say the street name. Do not include the direction (N, S, E, W) or type (St., Ave., Blvd., etc.).

- A list of street names will appear. Say the number listed next to the street you want to select.
  - 8 Say the entire street address number. For example, "1-2-5-0."
  - 9 The system will calculate the route and display the "Calculate route to" screen. Say "OK" to set the route.



#### Entering a Destination Using the "Find Nearest" Command

Try these simple steps to find a nearby point of interest, such as a gas station, movie theater, or restaurant.

# Press and release the NAVI TALK button before giving each command.

1. Say "Find nearest ATM."



A list of the nearest ATMs in your area will be displayed by shortest distance to destination.



3. Say the number of the destination you want.



 The system will calculate the route and display the "Calculate route to" screen. Say "OK" to set the route.



#### Commonly Used Voice Commands

# Navigation Commands

# General Commands

Accepted on map screen

- Display menu
- Display setup
- Display information
- Display audio screen
- Go home

Accepted on map screen (after a destination has been entered)

- · How long/far to the destination?
- Display destination
  - Display entire route

# Display Commands

Accepted on map screen

- Display or hide (choose one):
  - ATM/gas station/restaurant/etc.
- Display north up/heading up
- Zoom in/out

# Find Nearest Commands

Accepted on map screen

Find nearest (choose one):

- Mexican restaurant
- Gas station
- ATM
- Honda dealer

# Information

# i

### Help Commands

Accepted on most screens

- Help (The system reads and lists all available commands for the current screen.)
- Voice command help (The system reads and lists all navigation, audio, setup, and climate control commands.)

# Setup Commands

Accepted on the setup screen

- · Brightness up/down
  - Volume up/down/min/max/off
- Guidance prompts min/normal/max

# Audio/ Climate Control



### **Audio Commands**

- Accepted on most screens
- Radio on/off
- Radio # FM (# = frequency)
- Radio preset 1/2/3/4/5/6
- CD play
- AUX play

# **Climate Control Commands**

Accepted on most screens

- Air conditioner on/off
- Rear defrost on/off
- Climate control recirculate/fresh air
- Fan speed up/down
- Temperature # degrees (# = 57–87)
- Temperature up/down
  - Temperature max hot/cold

Check your owner's manual for additional information and instructions.