



Rear Seat Operation

Folding Rear Seat

Folding the Rear Seat(s) Up




Pull up the rear seat cushion and fold down the seat leg. Push the seat cushion firmly up against the seat-back to lock it in place.




To pull down the seat cushion, pull the seat leg completely up and push down on the seat cushion. Set the seat leg in the floor guide. A latch comes out when the leg is set properly.

Folding the Rear Seat(s) Down



Tip: When folding the driver's side rear seat, use the latch plate to release the center seat belt from the detachable anchor.

1. Lower the head restraints to their lowest positions.
2. Pull up on the release lever, and fold the seat-back forward.
3. Reverse this procedure to return the rear seat to the upright position.



Tip: When returning the seat-back to the upright position, make sure the seat is securely latched before driving.

* Check the owner's manual for additional information and instructions.