

## BLUETOOTH® HANDSFREELINK® (HFL) (if equipped)

Place and receive phone calls through your vehicle's audio system. Visit [handsfreelink.honda.com](http://handsfreelink.honda.com) to check if your phone is compatible.

### Pairing Your Phone



**HFL Talk button:** Give HFL commands or answer incoming calls.

**HFL Back button:** End a call, go back to the previous command, or cancel an operation.




Press and release the HFL Talk button before you give a command.

1. **Enable** "Discovery" or "Search" mode on your compatible phone.
2. **Say** "Phone setup," then say "Pair."



3. HFL gives you a four-digit code (that also appears on the MID) and begins to search for your phone.



4. **Search** for a HandsFreeLink device from your phone, and connect to HFL.




5. **Enter** the four-digit code on your phone when prompted.
6. HFL asks you to name the phone. For example, say "Mary's phone."



### Making a Call

Press and release the HFL Talk button before you give a command.

1. **Press** the HFL Talk button.
2. **Say** "Call" or "Dial" and the desired phone number.
3. **Press** the HFL Talk button, and say "Call" or "Dial" to continue.
4. The call is connected and heard through the vehicle's speakers.



### Receiving a Call

1. A notification is heard and the incoming phone number appears on the MID.
2. **Press** the HFL Talk button to accept the call.



3. **Press** the HFL Back button to end or decline the call.



## HFL Phonebook


Store up to 50 names and their phone numbers, which can be used as speed dials.

Press and release the HFL Talk button before you give a command.


1. **Say** "Phonebook."



2. **Say** "Store."



3. **Say** the name of the contact, and then the phone number.



4. To call a contact once an entry is stored, **say** "Call Mike."

