## INSTRUMENT PANEL INDICATORS

Briefly appear with each engine start. Red and amber indicators are most critical. Blue and green indicators are used for general information.



## Malfunction Indicators If an indicator remains on, there may be a problem; see your dealer





ABS (anti-lock brake system)





Malfunction lamp (check engine light)



VSA (vehicle stability assist)




SRS (supplemental restraint system)




BSI (blind spot information system)\*

## **Condition Indicators** Action is needed by driver






Seat belt reminder: Fasten seat belt(s)





Low fuel:



System message indicator: See MID

## On/Off Indicators PASSENGER AIRBAG OFF Fuel economy on (located on center panel) **Immobilizer** SIDE AIRBAG OFF Flashes: improperly coded key; use correct key VSA OFF Headlights on Blind Spot Indicator\* on Turn signals/hazards on CRUISE MAIN on High beams on CRUISE CONTROL on

\*Touring Elite only

Fog lights on