
# MULTI-INFORMATION DISPLAY (MID)

Consists of several displays that provide you with useful information.

### Accessing the MID






**Press** the INFO button to change main displays.









## Sub-displays





**Press** the SEL/RESET button to change sub-displays.



## Steering Wheel Controls



## (+) Button:


Press to scroll - upward.

### (◀) Button:

Press to go back to the previous display.

#### (-) Button: Press to scroll

downward.



# Display/Information Button:

Change

Change main displays.

## SOURCE Button:

Press to enter your selection.

### (▶) Button:

Press to go to the next display.

### MENU Button:

Press to go to "Vehicle Menu" for customization and other settings.