
## BLUETOOTH® HANDSFREELINK®

Place and receive phone calls through your vehicle's audio system. Visit handsfreelink.honda.com to check if your phone is compatible.

## Pairing Your Phone



HFL Talk button: Give HFL commands or answer incoming calls.

HFL Back button: End a call, go back to the previous command, or cancel anoperation.



#### 1. Enable "Discovery" or 4. Search for HandsFreeLink

Press and release the HFL Talk button before you give a command.

- "Search" mode on your compatible phone.
- 2. Say "Phone setup," then say "Pair."



3. HFL gives you a four-digit code that appears on the audio display.



from your phone, and enter the code when prompted. Connect to HFL.



phone. For example, say "Mary's phone." The phone is now added.



## Making a Call

#### 3. Say "Call" or "Dial" to continue. I. Press the HFL Talk button.

Press and release the HFL Talk button before you give a command.



0 347





0 947

through the vehicle's speakers.



### I. A notification is heard and the incoming phone number appears on the audio display.


Receiving a Call


0 947 3 10-555- 1234



2. Press the HFL Talk button to

accept the call.





3. Say the name of the contact,

and then the phone number.

0 347

# 1. Say "Phonebook."

2. Say "Store."


as speed dials.

3 10-555- 1234

Press and release the HFL Talk button before you give a command.



4. To call a contact once an entry is stored, say "Call Mike."



Cellular Phonebook\* (models with navigation)

Import your entire cell phone's address book to the navigation system. Press and release the Navi Talk button before you give a command.

Delete Imported

Phonebook



1. Say "Display Information."

Calendar Calculator


> Import Cellular Phonebook

> > PIN Number





4. To call a contact, say "Search



\*not available on all phones

0 9