

REVERSE TILT DOOR MIRRORS (if equipped)

When you shift into Reverse (R), you can tilt either outside door mirror down slightly to improve your view as you parallel park. Shifting out of Reverse returns the tilted mirror to its original position.

How It Works



- To tilt the driver's door mirror, **move** the mirror selector switch to the left (L) position.
- To tilt the passenger's side door mirror, **move** the mirror selector switch to the right (R) position.
- To turn the feature off, **move** the switch to the middle position.

