HIDDEN REMOVABLE UTILITY BOX

Removable and washable utility box provides extra storage and access to tool kit and jack.

Removing the Utility Box

I. Lift the removable tray using the handle.



 Secure the anchors to the designated hooks located on the side panels.





Remove the side anchors attached to the tray.





 Lift the utility box out from its compartment using the side handles.



The utility box also includes two removable dividers for added storage options, located behind each handle.