BLUETOOTH® HANDSFREELINK® (HFL) (models without navigation)

Place and receive phone calls through your vehicle's audio system. Visit handsfreelink.honda.com to check if your phone is compatible.

How to Use HFL

HFL Talk button: Give HFL commands or answer incoming calls."

HFL Back button: End a call, go back to the previous command, or cancel anoperation.



Pairing Your Phone

Press and release the HFL Talk button before you give a command.

- 1. Enable Discovery mode on your compatible phone.
- 2. Say "Phone setup," then say "Pair."



3. HFL gives you a four-digit code that also appears on the MID.



4. Search for HandsFreeLink from your phone, and enter the code when prompted. Connect to HFL.



5. HFL asks you to name the phone. For example, say "Mary's phone." The phone is now added.



Making a Call

Press and release the HFL Talk button before you give a command.

Press the HFL Talk button.



2. Say "Call" or "Dial" and the desired phone number.



3. Press the HFL Talk button, and say "Call" or "Dial" to continue.



4. The call is connected and heard through the vehicle's speakers.



Receiving a Call

the incoming phone number appears on the MID. RMT at

> INCOMING CALL

1. A notification is heard and




accept the call.

Press the HFL Talk button to



end or decline the call.



as speed dials.

HFL Phonebook Store up to 50 names and their phone numbers, which can be used

Press and release the HFL Talk button before you give a command. 3. Say the name of the contact,

1. Say "Phonebook."






STORE

and then the phone number.





3105551234