

## BLUETOOTH® HANDSFREELINK® (HFL)

Place and receive phone calls through your vehicle's audio system. Visit [handsfreelink.honda.com](http://handsfreelink.honda.com) to check if your phone is compatible.


### How to Use HFL

**Pick-Up button:** Go directly to the Phone screen, or answer an incoming call.

**Talk button:** Use to call speed dial entries with stored voice tags.

**Back button:** Cancel a selection.

**Hang-Up button:** End a call.



Use these two buttons to navigate through the HFL menus.

**Back button:** Press to cancel an operation or return to the previous screen.




**Audio selector knob:** Rotate to scroll through selections and press to make a selection.

### Pairing Your Phone

Use this pairing method when no phone has ever been paired to the system. You can only pair your Bluetooth-compatible phone when the vehicle is stopped.

Use the audio selector knob to make and enter selections.

1. **Press** the Pick-Up button to access the Phone screen. A prompt appears. **Select Yes.**



2. Make sure your phone is in discovery mode, and **select Continue.**




3. HFL searches for your phone. **Select** it when it appears on the list. **Go** to step 4.



*If your phone does not appear:*  
**Select** "Phone Not Found?" and **search** for a HandsFreeLink device from your phone. **Connect** to HFL. **Go** to step 4.



4. HFL gives you a four-digit code. **Enter** it on your phone when prompted. **Select OK** to complete.



## Pairing Your Phone (continued)

Use this pairing method when a phone has already been paired to the system, or when you want to pair an additional phone.

Use the audio selector knob to make and enter selections.

1. Press the Pick-Up button to access the Phone screen.
6. Make sure your phone is in Discovery mode, and select OK.



If a prompt appears asking to connect to a phone, select No and continue to step 2.

2. Select Phone setup.




3. Select Connection.




4. Select Add a New Phone.



5. Select an empty location for the phone.



7. HFL searches for your phone. Select your phone when it appears on the list.



If your phone does not appear:

Select "Find Another Phone" and search for HandsFreeLink from your phone. Connect to HFL. Go to step 4.



8. HFL gives you a four-digit code. Enter it on your phone when prompted. The phone is now paired.



## Dialing a Number

Use the audio selector knob to make and enter selections.

1. Press the Pick-Up button to go to the Phone screen.
3. Enter the phone number. Select the green Dial icon or press the Pick-Up button to call.



2. Select Dial.



4. The call is connected and heard through the vehicle speakers.



## Receiving a Call

1. A notification is heard and the incoming phone number appears on the center display screen.
3. Press the Hang-Up button to end or decline the call.



2. Press the Pick-Up button to accept the call.



## Using the Phonebook

When your phone is paired, its entire phonebook is automatically imported to the system.


Use the audio selector knob to make and enter selections.

1. **Press** the Pick-Up button to go to the Phone screen.
3. **Scroll** the list to find the name you want to call, and **press ENTER** to begin the call.



2. **Select** Phonebook.

4. The call is connected and heard through the vehicle speakers.



## Using Speed Dial

Up to 15 numbers can be stored with voice tags\*.


Use the audio selector knob to make and enter selections.

1. **Press** the Pick-Up button to go to the Phone screen.
3. **Scroll** through the list to find the name you want to call, and **press ENTER** to begin the call.



2. **Select** Speed Dial.

4. The call is connected and heard through the vehicle speakers.



\*When a voice tag is stored for a speed dial entry, you can make a call using voice commands. See your Owner's Manual for instructions.