

## iPod® OR USB FLASH DRIVE

Play audio files from your compatible iPod or USB flash drive through your vehicle's audio system.

### Connecting Devices and Playing Audio Files

1. **Open** the center console, and **pull out** the USB adapter cable.



2. **Connect** the USB connector to your iPod dock connector or flash drive.



3. **Press** USB/AUX to begin playing.



4. To change tracks, **rotate** the selector knob or **press** the SKIP (⏮) or (⏭) button.



iPod is a registered trademark of Apple Computer, Inc., registered in the U.S. and other countries. iPod not included.

EX-L shown

## BLUETOOTH® AUDIO

Play audio files from your compatible phone through your vehicle's audio system. Visit [handsfreelink.honda.com](http://handsfreelink.honda.com) to check if this feature is available on your phone.

### Playing Bluetooth Audio Files

1. Make sure your phone is on and paired to Bluetooth® HandsFreeLink® (see page 11).
2. **Press** USB/AUX until "Bluetooth Audio" appears on the screen.



3. From your phone, **open** the desired audio player or app and begin playing. Sound is redirected to the audio system.



4. Press (⏭) or (⏮) on the audio control panel or (+) or (-) on the steering wheel to change tracks.



#### NOTE:

- Make sure the volume on your phone is properly adjusted.
- You may need to enable additional Bluetooth settings on your phone for playback.
- The play/pause function may not be supported on all phones.
- Remote audio controls may not be supported on all phones.

EX-L shown

## CD LIBRARY

Store up to 18 audio CDs in the system memory.

### Recording an Audio CD

Use the audio selector knob to make and enter selections.

1. **Insert** an audio CD.



2. The system asks if you want to record the CD to memory. **Select** Yes.



3. **Select** the location to store the CD.



4. The CD records. If available, album information is displayed.



**NOTE:** Albums can only be selected from the CD library if recorded in their entirety. Partially recorded albums may appear, but cannot be played.

### Using the CD Library

Use the audio selector knob to make and enter selections.

1. **Press** CD/CDL. The last album recorded begins playing.




To change tracks, **press** the SKIP (⏮) or (⏭) button, or **rotate** the selector knob.

To change albums, **press** the CATEGORY (+) or (-) button.

2. To view the CD library, **press** the selector knob.



3. A list of recorded CDs appears. **Select** the album and track you want to hear.



EX-L shown