

USING THE TOUCHSCREEN

Interactive touchscreen display includes audio and *Bluetooth*® HandsFreeLink® functionality.

Audio Options



Source: Select audio sources.

Preset: Select preset stations or channels.



Skip/Seek: Change stations, channels, tracks, etc.

More: Select menu options and sound settings.

FM screen shown

Bluetooth® HandsFreeLink® Options*

When you enter the Dial screen from the Phone Menu, you can use the touchscreen to enter the number.




When you enter the Phonebook screen from the Phone Menu, you can use the touchscreen to search for names.




* Manual operation is inoperable while the vehicle is moving.

Sound/Screen Options

Select More from the main screen.



Select Sound Settings to adjust the audio system.



Select Screen Settings to adjust various screen features.