FORWARD COLLISION WARNING (FCW)

Alerts you to the possibility of a front-end collision.

How It Works

If the camera mounted in the center of the upper windshield detects a vehicle in front of you when your vehicle speed is 10 mph or higher—and it determines there is a likelihood of a frontal collision—the system provides you with visual and audible warnings.



FCW may not activate under certain conditions. See your Owner's Manual for more information.

Customizing FCW

Determine the warning timing, or turn the system off.

I. Press DISP.




2. Select Settings.



3. Select Vehicle Settings.




Select Forward Collision Warning Distance.



5. **Select** one of the options.

Long: early warning timing
Normal: standard warning timing
Short: late warning timing
Off: Turn the system off



6. Press BACK to exit the menu.

