BLUETOOTH ANDSFREELINK (models with navigation)

Make and receive phone calls through your vehicle's audio system. Visit handsfreelink.honda.com to check if your phone is compatible.

To reduce the potential for driver distraction, certain manual and touch screen functions may be inoperable or grayed out while the vehicle is moving. Voice commands are always available.

How to Use HFL

a call.

call, or go directly to the Phone screen. **Talk button:** Give HFL commands.

Pick-Up button: Answer an incoming

Hang-Up button: End a call or decline

Back button: Cancel a command or return to the previous screen.




can pair your compatible phone only when the vehicle is stopped.


Pairing Your Phone

Press and release the Talk button before you say a command.

I. **Press** the Pick-Up button to If your phone does not appear: go to the Phone screen. A Say "Find Another Phone" and

prompt appears. Say "Yes."








device from your phone. Connect to HFL.

search for a HandsFreeLink








when you want to pair an additional phone. Press and release the Talk button before you say a command.


Pairing Your Phone (continued)

I. **Press** the Pick-Up button to 5. Make sure your phone is in discovery mode, and say "OK." go to the Phone screen.

Use this pairing method when a phone has already been paired to the system, or




3. Say "Add a new phone."





6. HFL searches for your phone. Say the number next to the phone

when it appears on the list.



Paired Plone List Add a New Phone

7. HFL gives you a four-digit code.

Say "Find Another Phone" and

search for HandsFreeLink from

your phone. Connect to HFL.



I. **Press** the Pick-Up button to go to the Phone screen.

PHONE

2. **Say** "Dial."

Dialing a Number

CONNECTED PHONE BlackBerry 9300 Speed Dial 1 Speed Dial 2

Redial

Dial

Enter a 10-digit phone number to call.

Call History Text Message Delete Phonebook | Phone Setup

Press and release the Talk button before you say a command.



Press the Pick-Up button to

accept the call.

Phonebook

Using Speed Dial

through the vehicle speakers. Dialing...

4. The call is connected and heard


Dial

3. Say the entire phone number,

then **say** "Dial" to call.

Dial

123456789.



Press the Hang-Up button to

end or decline the call.


Receiving a Call

A notification is heard and the following screen appears:

Incoming call

Answer Ignore

Unknown



Phone Setup

Phone Setup

Ottol

3. **Scroll** through the list to find the name and number you want

9


Pick-Up button to call.

Contact C

Contact AA Contact AB

123456789

2. Say "Phonebook." 4. The call is connected and heard through the vehicle speakers. Dialing...



Phonebook

Store up to 15 numbers for quick calling. See your Navigation Manual for Press and release the Talk button before you say a command.

If an entry has a stored voice tag,

say "Dial by voice tag," followed by the voice tag name and "Dial"

from any screen.

Say the name or number to dial

- 12 M

say the number or voice tag.

2. Say "Speed Dial I" (or "Speed Dial 2") and the number next to the entry. For example, 3. The call is connected and heard "One." Say "Call," or press the Pick-Up button to call. through the vehicle speakers.

To reduce the potential for driver distraction, certain functions may be inoperable or grayed out while the vehicle is moving. You may have to use voice commands, stop or pull over to perform the function. The chart below shows a list of some operations that are restricted while the vehicle is moving. **Function Restriction Level While Driving**

Restricted

Restricted

Not restricted

HFL System (Without Navigation) 10-key dial Phonebook

Driver Distraction

Speed dial

Connect to new phone

Speed dial setup Restricted Call history Not restricted Call history scroll Not restricted Redial Not restricted Restricted Connect to a new phone Connect to a previously paired phone Not restricted Manual dial tones Restricted Read text Restricted Reply to text Not restricted **HFL System (With Navigation)** 10-key dial Voice command only Phonebook Voice command only. Limited to three screens Speed dial Not restricted Speed dial setup Restricted Call history Not restricted Call history scroll Voice command only. Limited to three screens Not restricted Redial

Restricted

