

# VOICE RECOGNITION

To keep your eyes on the road and hands on the wheel, use voice commands for hands-free calling, navigation, and audio. For a full list of commands, say “Display Information” and “Voice Info.”

## Key Functions by Voice Command

Control four different systems with the steering wheel buttons and the ceiling microphone.

**To reduce the potential for driver distraction, certain manual and touch screen functions may be inoperable or grayed out while the vehicle is moving. Voice commands are always available.**



**Pick-Up button:** Answer an incoming call, or go directly to the Phone screen.

**Hang-Up/Back button:** End a call, decline an incoming call, or cancel a selection.

**Talk button:** Give navigation, HFL, audio, or climate control commands.



## Voice Command Tips

- **Press and release** the Talk button, wait for a beep, then say a command.
- All available voice commands are highlighted in blue when you press the Talk button.
- For a list of available commands, **press and release** the Talk button and say “Help” at any time.
- Speak in a clear, natural voice.
- Reduce all background noise.
- Adjust the dashboard and side vents away from the microphone in the ceiling.
- Close the windows.
- The system also uses a touchscreen display. You can select options or icons by touching them on the screen. This is limited while the vehicle is moving.

## Commonly Used Voice Commands

Here are some examples of commonly used voice commands. Try some of these to familiarize yourself with the voice command system.

Press and release the Talk button before you say a command.

### General Commands

(Accepted on most screens to change displays)


- Display map
- Display menu
- Display information
- Display audio
- What time is it?
- Next/previous (to change pages)
- Left/right (to change tabs)
- Up/down (to scroll lists up to three pages)



### Find Place Commands

(Accepted on Map screen)


- Find nearest:
  - ATM
  - gas station
  - Mexican restaurant
  - post office
  - Honda dealer
  - airport
  - hospital
  - bank



### Navigation Commands

(Accepted on Map screen)


- How long/far to the destination?
- Display destination map
- Display entire route



### Display Commands

(Accepted on Map screen)

- Display/Hide:
  - ATM
  - gas station
  - restaurant
  - post office
- Display north up/heading up
- Zoom in/out
- Go home
- Display current location




Press and release the Talk button before you say a command.

### Audio Commands

(Accepted on most screens)


- Radio on
- Radio # FM/AM
- Radio preset 1/2/3/4/5/6
- DISC/USB/iPod play
- DISC/USB/iPod skip forward/back
- Auxiliary (AUX) play



### Phone Commands

(Accepted on Phone screen)

- Dial
- Speed Dial 1 (or 2)
- Redial
- Phonebook
- Phone setup



### Climate Control Commands

(Accepted on most screens)

- Air conditioner on/off
- Rear defrost on/off
- Climate control recirculate/fresh air
- Fan speed up/down
- Temperature # degrees (# = 57–87)
- Temperature max hot/cold



### Help Commands

(Accepted on most screens)

- Help (list of available commands for current screen)
- Voice info - from INFO screen (list of all available commands by category)

