

## REAR ENTERTAINMENT SYSTEM (RES)

With the rear entertainment system and headphones, rear passengers can enjoy a different entertainment source than the front seat occupants.

### RES Front Panel Controls



### Rear Entertainment System



**Pull down** the bottom edge of the screen to open it.



**Extend** the screen until it locks into place.



**Pivot** the earpieces to turn on or off. Wireless headphones work only in the rear seats.



Wired headphones may also be used.

### Operating the RES from the Front

1. **Press REAR POWER.** Rear passengers will hear audio through the headphones.



2. **Press REAR SOURCE.** Select an entertainment source for the rear passengers.




3. **Press REAR SOURCE** again to return to the front audio controls.



### Operating the RES from the Rear

1. **Press REAR POWER** on the front audio panel. **Open** the overhead screen.



2. **Press DVD/AUX, CD/CDL, XM, or FM/AM.**



3. **Press** the (▲) (▼) (◀) (▶) buttons to navigate the menu options. **Press ENTER** to select an option.



4. The rear control panel can be detached and used as a remote control. **Press** the release button to remove it.

