# **VOICE RECOGNITION**

To keep your eyes on the road and hands on the wheel, use voice commands for hands-free calling, navigation, audio, and climate control. For a full list of commands, say "Information" and "Voice Help."

## Key Functions by Voice Command

Control four different systems with the steering wheel buttons and the ceiling microphone.






**Pick-Up button:** Answer an incoming call, or go directly to the Phone screen.

**Talk button:** Give HFL, navigation, audio, or climate control commands.

**Back button:** Cancel a command and – return to the previous screen.

Hang-Up button: End a call or decline a call.



## Voice Command Tips

- To hear a list of available commands at any time, press and release the Talk button, then say "Help."
- When using the Talk button, wait for a beep, then say a command.
- When the Talk button is pressed, all available voice commands are highlighted in blue.
- Speak in a clear, natural voice.
- Reduce all background noise.
- Adjust the dashboard and side vents away from the microphone in the ceiling.
- Close the windows.

## **Commonly Used Voice Commands**

Here are some examples of commonly used voice commands. Try some of these to familiarize yourself with the voice command system.

Press and release the Talk button before you say a command.


General Commands (Accepted on most screens to change displays)

- Display map
- Display menu
- Display phone
- Information
- Display audio screen
- What time is it?



## Find Place Commands (Accepted on Map screen)


- Find nearest: - ATM
  - Honda dealer
  - gas station - airport
  - Mexican - hospital



- bank restaurant - post office
- 3 III PILOT BANK 4 MACCORD BANK

### Navigation Commands (Accepted on Map screen)

- How long/far to the destination?
- Display destination map
- Display entire route



## Display Commands (Accepted on Map screen)

- Display (or hide):
  - ATM
  - gas station
  - restaurant
  - post office
- Display north up/heading up
- Zoom in/out
- Go home
- Display current location

#### 2 207TH 208 TH DOMINGUEZ. 1001 SERRA LORRANCE .mm De Land 2MTH CONTO 215 THE MER

## Press and release the Talk button before you say a command.

## Audio Commands (Accepted on most screens)

- Radio on
- Radio # FM/AM
- Radio preset 1/2/3/4/5/6
- XM channel #
- XM preset 1/2/3/4/5/6

CH PTY FREQ	97.1 мн	z u		FM1 STEREO
		F)	12	
	90.1	18	43	98.1
87.9		- 24	1	106.1
	87.9			107.9
		AUDIO	MENU	

- DISC playDISC play track #
- DISC skip forward/back
- iPod/USB/HDD play

### Setup Commands (Accepted on Setup screen)

- Brightness up/down
- Volume up/down/min/max/off
- Interface dial feedback off/auto/on



## Climate Control Commands (Accepted on most screens)

- Air conditioner on/off
- Rear defrost on/off
- Climate control recirculate/ fresh air
- Fan speed up/down
- Temperature # degrees (# = 57 - 87)
- Temperature max hot/cold

### Help Commands (Accepted on most screens)

- Help (list of available commands) for current screen)
- Voice help (from INFO screen list of all available navigation, audio, and climate control commands)



