

REAR ENTERTAINMENT SYSTEM (RES)

With the rear entertainment system and headphones, rear passengers can enjoy a different entertainment source than the front seat occupants.

RES Front Panel Controls



Rear Entertainment System



Press OPEN to release the overhead screen.



Pivot the overhead screen to fully open it.



Pivot the earpieces to turn on or off. Wireless headphones only work in the rear seats.



Wired headphones may also be used.

Operating the RES from the Front

1. **Press REAR POWER.** Rear passengers will hear audio through the headphones.



3. **Press REAR SOURCE** again to return to the front audio controls.



2. **Press REAR SOURCE.** Select an entertainment source for the rear passengers.



Operating the RES from the Rear

1. **Press REAR POWER** on the front audio panel. **Open** the overhead screen.



3. **Press** the (▲) (▼) (◀) (▶) buttons to navigate the menu options. **Press ENTER** to select an option.



2. **Press DVD/AUX, CD/CDL, XM, or FM/AM.**



4. The rear control panel can be detached and used as a remote control. **Press RELEASE** to remove it.

