

VOICE RECOGNITION (if equipped)

To keep your eyes on the road and hands on the wheel, use voice commands for hands-free calling, navigation, audio, and climate control. For a full list of commands, say **"Information"** and **"Voice Command Help."**

Key Functions by Voice Command

Control four different systems with the steering wheel buttons and the ceiling microphone.




HFL Talk button: Give HFL commands or answer incoming calls.

Navi Talk button: Give navigation, audio, and climate control commands.

Navi Back button: Cancel a command or return to the previous screen.

HFL Back button: End a call, go back to the previous command, or cancel an operation.



NAVIGATION p. 14



BLUETOOTH® HANDSFREELINK® p. 16



AUDIO p. 13



CLIMATE p. 13



Voice Command Tips

- **Press and release** the HFL or Navi Talk button, wait for a beep, then say a command.
- For a list of available HFL commands, **press and release** the HFL Talk button and say **"Hands-free help."**
- For a list of available navigation commands, **press and release** the Navi Talk button and say **"Help."**
- Speak in a clear, natural voice.
- Reduce all background noise.
- Adjust the dashboard and side vents away from the microphone in the ceiling.
- Close the windows.

Commonly Used Voice Commands

Here are some examples of commonly used voice commands. Try some of these to familiarize yourself with the voice command system.

Press and release the Navi Talk button before you say a command.

General Commands (Accepted on most screens to change displays)

- Display map
- Display menu
- Information
- Display audio screen
- What time is it?




Find Place Commands (Accepted on Map screen)

- Find nearest:
 - ATM
 - gas station
 - Mexican restaurant
 - post office
 - Honda dealer
 - airport
 - hospital
 - bank




Navigation Commands (Accepted on Map screen)

- How long/far to the destination?
- Display destination map
- Display entire route



Display Commands (Accepted on Map screen)


- Display (or hide):
 - ATM
 - gas station
 - restaurant
 - post office
- Display north up/heading up
- Zoom in/out
- Go home
- Display current location



Press and release the Navi Talk button before you say a command.


Audio Commands (Accepted on most screens)

- Radio on
- Radio # FM/AM
- Radio preset 1/2/3/4/5/6
- XM channel #
- XM preset 1/2/3/4/5/6
- CD play
- CD play track #
- CD skip forward/back
- Auxiliary (AUX) play



Setup Commands (Accepted on Setup screen)

- Brightness up/down
- Volume up/down/min/max/off
- Guidance prompts min/max/normal



Climate Control Commands (Accepted on most screens)

- Air conditioner on/off
- Rear defrost on/off
- Climate control recirculate/fresh air
- Fan speed up/down
- Temperature # degrees (# = 57-87)
- Temperature max hot/cold



Help Commands (Accepted on most screens)

- Help (list of available commands for current screen)
- Voice command help (from INFO screen - list of all available navigation, audio, and climate control commands)

