BLUETOOTH R HANDSFREELINK (HFL)

Place and receive phone calls through your vehicle's audio system. Visit handsfreelink.honda.com to check if your phone is compatible.

To reduce the potential for driver distraction, certain manual and touch screen functions may be inoperable or grayed out while the vehicle is moving. Voice commands are always available.

How to Use HFL



call or go directly to the Phone screen. Hang-Up/Back button: End a call, decline an incoming call, or cancel a

Pick-Up button: Answer an incoming



selection.

Talk button: Give HFL commands.



right to scroll options, and press to make a selection.

Joystick/ENTER button:

Move up, down, left, or



CANCEL button: Press to cancel an operation or return to the previous screen.

Phone screen.

PHONE button:

Go directly to the

Press and release the 🔟 Talk button before you say a command.

Pairing Your Phone

I. Press PHONE to go to the Phone screen. A prompt appears. Say "Yes."

Use this pairing method when no phone has ever been paired to the system. You

can pair your compatible phone only when the vehicle is stopped.

3. HFL searches for your phone. Say the number next to the phone when it appears on the list.

If your phone does not appear:

phone is now paired.

mode. Say "OK."

2. Make sure your phone is in discovery


Say "Find another phone," and search for HandsFreeLink from your phone. Connect to HFL. 4. HFL gives you a four-digit code. Enter it

on your phone when prompted. The

Use this pairing method when a phone has already been paired to the system, or when you want to pair an additional phone.

I. Press PHONE to go to the Phone

screen. If a prompt appears asking to



connect to a phone, say "No." 2. Say "Phone setup."

Press and release the 🔟 Talk button before you say a command.

3. Say "Bluetooth setup add select a phone." 4. Say "Search."

6. HFL searches for your phone. Say the number next to the phone when it appears on the list.

Say "Find Another Phone," and search for

If your phone does not appear:

5. Make sure your phone is in discovery

mode. Say "OK."

Connect to HFL.

7. HFL gives you a four-digit code. Enter it on your phone when prompted. The phone is now paired.


HandsFreeLink from your phone.

Dialing a Number Enter a 10-digit phone number to call.

I. Press PHONE to go to the Phone

3. Say the entire phone number. For





example, "3-1-0-5-5-1-2-3-4." 4. Say "Dial" to begin the call.

Using the Phonebook

screen.

Using Speed Dial

Receiving a Call

screen.

2. Say "Dial."

I. Press PHONE to go to the Phone

4. Say "Call" to begin the call.

instructions on storing voice tags.

For example, "One."

3. Say "Call" to begin the call.

and "Dial" from any screen.

When your phone is paired, its entire phonebook is automatically imported to the system. This feature is inoperable when the vehicle is moving. Press and release the Fig. Talk button before you say a command.

2. Say "Phonebook." 3. Scroll through the list to find the name and number you want.

Store up to 15 numbers for quick calling. See your Navigation Manual for

Press and release the E Talk button before you say a command.

4 16 E Answer Ignore

Note: You can also say "Dial by number," followed by the phone number


I. Press PHONE to go to the Phone screen.

2. Say "Speed Dial I" (or "Speed Dial 2") and the number next to the entry.

- followed by the voice tag name and "Dial" from any screen.
- A notification is heard and the following screen appears: Incoming call 3105554475
- Note: If an entry has a stored voice tag, you can say "Dial by voice tag,"

Press the (Pick-Up)

button to answer the call.



Driver Distraction

Press the (Hang-Up) button

to end or decline the call.

Restriction Level While Driving

To reduce the potential for driver distraction, certain functions may be inoperable or grayed out while the

HFL System (Without Navigation)	
10-key dial	Restricted
Phonebook	Restricted
Speed dial	Not restricted
Speed dial setup	Restricted
Call history	Not restricted
Call history scroll	Not restricted
Redial	Not restricted
Connect to a new phone	Restricted
Connect to a previously paired phone	Not restricted
Manual dial tones	Restricted
Read text	Restricted
Reply to text	Not restricted
HFL System (With Navigation)	
10-key dial	Voice command only
Phonebook	Voice command only. Limited to three screens
Speed dial	Not restricted
Speed dial setup	Restricted
Call history	Not restricted
Call history scroll	Voice command only. Limited to three screens
Redial	Not restricted
Connect to new phone	Restricted