


REAR ENTERTAINMENT SYSTEM (RES) (if equipped)

Rear passengers can enjoy a different audio or entertainment source than the front seat occupants.

Rear Entertainment System



Pivot the earpieces to turn the wireless headphones on or off. Wireless headphones work only in the rear seats.



Press OPEN to release the screen.




Extend the screen until it locks into place.




Operating the RES


1. Press REAR POWER in the center console. Open the overhead screen.



2. Insert a DVD or CD in the center console slot. Playback begins automatically.



3. Use the remote control to navigate the DVD or CD.



Note: To hear the RES source from all speakers, press AUX on the audio panel until RES mode appears.