


SIRI EYES FREE MODE

Activate Siri through your vehicle when an iPhone® is paired to the system. Visit handsfreelink.honda.com to check if this feature is compatible with your phone.

How It Works


Make sure your phone is paired to *Bluetooth*® HandsFreeLink® before using Siri in the vehicle.



To activate Siri: Press and hold the Talk button until the Smartphone screen appears and you hear the Siri tone. Say your Siri command.

If you only press and release the Talk button, the standard voice recognition system is activated.

To cancel a command: Press the Back button.



Siri Commands

Here are some examples of Siri commands:

- "Call John Smith"
- "Read my new text message"
- "Find a nearby sushi restaurant"
- "Remind me to pick up dinner"
- "Set up a meeting today at 3 p.m."
- "Play song XYZ"

Notes:

- Any requests that include visual feedback from Siri on your phone are not displayed in the vehicle.
- Certain commands rely on the iPhone's features and existing apps.
- To hear turn-by-turn directions or songs through the vehicle, set the audio mode to *Bluetooth*® Audio.