REARVIEW CAMERA

For added convenience, the area behind your vehicle is displayed to help you navigate while backing up.

How It Works

- When you shift into Reverse (R), a real-time image of the area behind your vehicle is shown in the i-MID, along with yellow parking guidelines.
- The display turns off when you shift out of Reverse.



