



INFORMATION DISPLAY

Consists of several displays that provide you with useful information.

Accessing the Information Display



When you start the engine, the information display shows your last active selection from the previous drive cycle.




To toggle between the different displays, press and release the select/reset knob.


Information Displays



Odometer, Trip meter A



Outside temperature, Trip meter A



Oil life



Outside temperature, Trip meter B

