# NAVIGATION

Real-time navigation system uses GPS and a map database to show your current location and help guide you to a desired destination.

### Entering a Destination Using Voice Commands

Set a destination using a street address. For other destination options, see your Navigation Manual.

Press and release the  $\frac{1}{100}$  Talk button before you say a command.

I. Say "Display menu." Say "Address."



2. Say "Street," then say the street name on the next screen. Do not include the direction (N, S, E, W) or type (St., Ave., Blvd., etc.).



3. A list of street names appears. Say the number next to the street you want to select.

2 MAIN 2 MAIN BRANCH	*	LOS ANGELES, C	A 12 mi 🗣
MAIN CHAMBERLAIN		and the second se	Destination Map
MAIN DAM C G		Nº Address B	ook View Routes
MAIN DIVIDE		My Dest	
MAIN DIVIDE TRUCK	Ŧ	<. su	Set as Dest.

4. Say the entire street address number, followed by "OK" if necessary. For example, "1-2-3-4 **OK.**"

<b>Ente</b> 1234.	r st	ree	nu	mbe	r .				-	i M <sup>ala</sup>
TE	2	3	4	5	6	7	8	9	0	
	8		Ð	Ē	F		H			
К		10	N	0		n	R		7	
U		W								
De	lete		min		-	6			OK	

5. If the street address is in more than one city, a list of city names appears. Say the number next to the city you want to select.

12911	me address appears in more than one city.				
EIV .	Distance	City			
TORRAN	NCE:	1.841-2	E		
WILMIN	GTON	4.0ml 😵	-		
STUDIO	CITY	20+1 👌			
ORANGE		26+10+	5		

6. The system displays the "Calculate route to" screen. Say "Set as destination" to set the route.

13 mi Destination Ma
No Address Book View Routes
My Dest, Route Pref.
C. Cill Set as Dest.

vehicle is stopped.

# Using the "Find Nearest" Command

Find a nearby point of interest, such as a gas station, movie theater, restaurant, etc.

Press and release the  $\cancel{w}$  Talk button before you say a command.

I. From the map screen, say "Find nearest ATM."



2. A list of the nearest ATMs in your area is displayed by shortest distance to destination.

Select a place	71
12545 N ATM1 AVE. CITV. STA 13101655-1254	ite Lami 🦻
I MEATM 1	1
≥ BIB ATM 2	10
S BELATM 3	
- BELATM 4	
5 EEB ATM 5	


3. Say the number next to the destination you want to select.

Select a place 70	nto 👐 🛛 📼
67890 S ATM3 ST. CITY. STATE 1510/556-5678	6.4ml 🤻
I IIII ATM 1	1
a ms ATM 2	-
I HER ATM 3	
- EES ATM 4	
EE ATM 5	

4. The system displays the "Calculate route to" screen. Say "Set as destination" to set the route.

Calculate route to		Em Brot Em	
6789	DE BANK 10 S ATM3 ST 1, STATE	0.5 mi 🗣 Destination Map	
A10 10	Address Book	View Routes	
A40 10	My Dest,	Route Pref.	
22	Gall	Set as Dest.	

### Map Screen Legend




# FM Traffic

Provides continuously updated information, including traffic speed, incidents, and construction in major metro areas. Works in cities where a clear FM traffic signal is available.

Press and release the  $\cancel{w}$  Talk button before you say a command.

Displaying Traffic Information Say "Display traffic" to view highway flow data.



#### Heavy traffic

Moderate traffic


**Note:** Traffic flow and incident icons are only displayed on map scales of 5 miles or less.



#### **Traffic Icons**










Construction

Weather

## Traffic Rerouting

When a destination is already set, you can create a detour to avoid traffic incidents or congestion.


I. Say "Display traffic list" to view a list of incidents on your route.




3. Say "Avoid," and the incident list returns.

S Congestion	-
GA-91 E 20 mpn for 2	2 mi
Avoid	Return

2. Say the number of the incident you want to avoid. When the incident appears, say "Traffic detail."



4. Say "Reroute" to set the new route.



### **Driver Distraction**

To reduce the potential for driver distraction, certain functions may be inoperable or grayed out while the vehicle is moving. You may have to use voice commands, stop or pull over to perform the function.

The chart below shows a list of some operations that are restricted while the vehicle is moving.

Function	<b>Restriction Level While Driving</b>
Navigation System	
Address	Voice command only
Place category	Not restricted
Place category scroll	Voice command only. Limited to three screens
Place name	Voice command only
Go home	Not restricted
Previous destination	Not restricted
Previous destination scroll	Voice command only. Limited to three screens
Address book	Not restricted
Address book scroll	Voice command only. Limited to three screens
Place phone number	Voice command only
Coordinate	Voice command only
Intersection	Voice command only
Map scroll	Limited use
Map point set as destination	Restricted
Destination list edit	Restricted
Route avoid street	Restricted
Route add waypoint	Restricted