INFORMATION DISPLAY

Consists of several displays that provide you with useful information.

Accessing the Information Display






When you start the engine, the display shows your last active selection from the previous drive cycle.



To toggle between the different displays, press and release the select/reset knob repeatedly.

Information Displays





Fuel range, Instant fuel economy







Oil life





Trip meter A/B, Average fuel economy

