

# INTELLIGENT MULTI-INFORMATION DISPLAY (i-MID)

Choose what to display in the upper screen.

## Changing the Display



Press the display button to change the main displays.




## Display Options

**Audio**  
Shows current audio information.




**Current Drive**  
Shows instant fuel, average fuel, and range for the current drive.



**Clock (or wallpaper)**  
Shows the clock or an imported image.\*



**Trip Computer**  
Shows average fuel and distance for the current and past three drives.



\*See your Owner's Manual for instructions on how to upload a wallpaper image.