

# Federal and California Emissions Warranties Parts List

Emissions warranties are state specific. Refer to the years/miles<sup>1</sup> columns below as follows:

- A – Minimum coverage for all vehicles in all states
- B – Vehicles registered and normally operated in California, Connecticut, Delaware, Maine, Maryland, Massachusetts, New Jersey, New York, Oregon, Pennsylvania, Rhode Island, Vermont, and Washington

System Covered/Part Name	A	B	System Covered/Part Name	A	B
<b>Crankcase Control System</b>			<b>Ignition System</b>		
Positive Crankcase Ventilation (PCV) Valve	3/36	3/50	Ignition Coils	3/36	3/50
Engine Oil Fill Cap	3/36	3/50	Spark Plugs <sup>3</sup>	3/36	3/50
<b>Evaporative and Refueling Emissions Control System</b>			Crankshaft Position Sensor	3/36	3/50
Fuel Tank (including Vapor Control Valve and Vapor Recirculation Tube)	3/36	<b>7/70</b>	Camshaft Position Sensors	3/36	3/50
Fuel Fill Pipe	3/36	<b>7/70</b>	<b>OBD System</b>		
Fuel Filter <sup>2</sup>	3/36	3/50	Data Link Connector (DLC)	3/36	<b>7/70</b>
Fuel Pressure Regulator	3/36	3/50	Malfunction Indicator Lamp (MIL)	3/36	<b>7/70</b>
Fuel Level Sensor	3/36	3/50	CAN Gateway (including software updates)	3/36	3/50
Fuel Filler Neck Restrictor	3/36	3/50	<b>Transmission Control System</b>		
Evaporative Emission Lines and/or Hoses	3/36	3/50	Transmission Control Module (including software updates)	<b>8/80</b>	<b>8/80</b>
Evaporative Emission Canister	3/36	3/50	CVT Pressure Control Solenoid Valve Set	3/36	<b>7/70</b>
Evaporative Emission Canister Purge Nozzle	3/36	3/50	CVT Input Shaft Speed Sensor	3/36	3/50
Evaporative Emission Valves	3/36	3/50	Turbine Shaft Speed Sensor	3/36	3/50
Evaporative Emission Leak Check Module	3/36	3/50	Vehicle Speed Sensor	3/36	3/50
<b>Exhaust System</b>			Transmission Range Switch	3/36	3/50
Catalytic Converters	<b>8/80</b>	<b>8/80</b>	Transmission Fluid Temperature Sensor	3/36	3/50

# Federal and California Emissions Warranties Parts List

System Covered/Part Name	A	B	System Covered/Part Name	A	B
<b>Fuel Injection System</b>			<b>Intake Air System</b>		
Engine Control Module (including Barometric Pressure Sensor and software updates)	8/80	8/80	Throttle Body (including Throttle Position Sensor and Throttle Actuator)	3/36	3/50
Injectors	3/36	7/70	Mass Airflow Sensor	3/36	3/50
Fuel Rails	3/36	7/70	Intake Air Temperature Sensor	3/36	3/50
High Pressure Fuel Pump	3/36	7/70	Intake Manifold Assembly	3/36	3/50
Fuel Rail Pressure Sensor	3/36	7/70	Turbocharger Assembly	3/36	7/70
Fuel Lines and/or Hoses	3/36	3/50	Turbocharger Wastegate Control Actuator	3/36	7/70
Knock Sensor	3/36	3/50	Turbocharger Bypass Control Valve	3/36	3/50
Oxygen Sensor	3/36	3/50	Turbocharger Bypass Control Solenoid Valve	3/36	3/50
Air Fuel Ratio Sensor	3/36	3/50	Turbocharger Boost Sensor	3/36	3/50
Manifold Absolute Pressure (MAP) Sensor	3/36	3/50	Charge Air Cooler	3/36	3/50
Engine Coolant Temperature Sensors	3/36	3/50	Air Cleaner Housing	3/36	3/50
Thermostat	3/36	3/50	Air Cleaner Housing Cover	3/36	3/50
Accelerator Pedal Module (including Pedal Position Sensor)	3/36	3/50	Air Cleaner Element <sup>3</sup>	3/36	3/50
<b>Valve Control System</b>			Intake Air Resonator	3/36	3/50
Variable Valve Timing Control Actuators	3/36	7/70	Intake Air Ducts	3/36	3/50
Variable Valve Timing Oil Control Solenoid Valves	3/36	3/50	<b>Miscellaneous Parts</b> that are used in conjunction with the items in this list are covered. Some examples are clamps, brackets, piping, nuts, bolts, fasteners, switches, sensors, solenoids, wires, harnesses, connectors, seals, software updates, and gaskets.		

<sup>1</sup> Coverage in years or 1,000 miles, whichever comes first.

<sup>2</sup> Fuel filter replacement and fuel tank flushing are covered when contamination results from a defect in material or workmanship.

<sup>3</sup> Covered up to the first required replacement only; see the maintenance schedule in the owner's manual.

# Federal and California Emissions Warranties Parts List

Emissions warranties are state specific. Refer to the years/miles<sup>1</sup> columns below as follows:

- A – Minimum coverage for all vehicles in all states
- B – Vehicles registered and normally operated in California, Connecticut, Delaware, Maine, Maryland, Massachusetts, New Jersey, New York, Oregon, Pennsylvania, Rhode Island, Vermont, and Washington

System Covered/Part Name	A	B	System Covered/Part Name	A	B
<b>Crankcase Control System</b>			<b>Exhaust System</b>		
Positive Crankcase Ventilation (PCV) Valve	3/36	15/150	Catalytic Converter	8/80	15/150
Engine Oil Fill Cap	3/36	15/150	<b>Ignition System</b>		
<b>Evaporative and Refueling Emissions Control System</b>			Ignition Coils	3/36	15/150
Fuel Tank (including Vapor Control Valve and Vapor Recirculation Tube)	3/36	15/150	Spark Plugs <sup>3</sup>	3/36	15/150
Fuel Pressure Regulator	3/36	15/150	Crankshaft Position Sensor	3/36	15/150
Fuel Filter <sup>2</sup>	3/36	15/150	Camshaft Position Sensors	3/36	15/150
Fuel Level Sensor	3/36	15/150	<b>OBD System</b>		
Fuel Fill Pipe	3/36	15/150	Malfunction Indicator Lamp (MIL)	3/36	15/150
Fuel Filler Neck Restrictor	3/36	15/150	Data Link Connector (DLC)	3/36	15/150
Evaporative Emission Lines and/or Hoses	3/36	15/150	CAN Geteway (including software updates)	3/36	15/150
Evaporative Emission Canister	3/36	15/150	<b>Transmission Control System</b>		
Evaporative Emission Leak Check Module	3/36	15/150	Transmission Fluid Temperature Sensor	3/36	15/150
Evaporative Emission Valves	3/36	15/150	<b>Valve Control System</b>		
<b>Exhaust Gas Recirculation (EGR) System</b>			Rocker Arm Oil Control Valve Assembly	3/36	15/150
Exhaust Gas Recirculation (EGR) Valve (including EGR Valve Position Sensor)	3/36	15/150	Rocker Arm Control Oil Pressure Sensor	3/36	15/150
EGR Pipe	3/36	15/150	Variable Valve Timing Control Actuator	3/36	15/150
EGR Cooler	3/36	15/150	Electric Variable Valve Timing Control Motor	3/36	15/150

# Federal and California Emissions Warranties Parts List

System Covered/Part Name	A	B	System Covered/Part Name	A	B
<b>Fuel Injection System</b>			<b>Hybrid System</b>		
Powertrain Control Module (including Barometric Pressure Sensor and software updates)	8/80	15/150	Battery Assembly (including all internal components)	8/100	10/150
Injectors	3/36	15/150	Drive Motor Control Module (including all internal components and software updates)	8/100	15/150
Fuel Rail	3/36	15/150	Battery Control Module (including all internal components and software updates)	8/100	15/150
Fuel Lines and/or Hoses	3/36	15/150	Drive Motor / Generator Stators and Rotors (including all internal components and Position Sensors)	8/100	15/150
Knock Sensor	3/36	15/150	High Voltage and Bypass Contractors, Resistor and Fuse	8/100	15/150
Oxygen Sensor	3/36	15/150	High Voltage Power Cables	8/100	15/150
Air Fuel Ratio Sensor	3/36	15/150	Battery Module Switch	3/36	15/150
Manifold Absolute Pressure (MAP) Sensor	3/36	15/150	Busbars	3/36	15/150
Engine Coolant Temperature Sensors	3/36	15/150	Battery Current Sensor	3/36	15/150
Thermostat	3/36	15/150	Electronics Coolant Pump Assembly	3/36	15/150
Electric Engine Coolant Pump	3/36	15/150	Motor Control Module Coolant Radiator Assembly	3/36	15/150
Accelerator Pedal Module (including Pedal Position Sensors)	3/36	15/150	Motor Control Module Coolant Expansion Tank Assembly	3/36	15/150
<b>Intake Air System</b>			Intelligent Power Unit Module Fan	3/36	15/150
Throttle Body (including Throttle Position Sensor and Throttle Actuator)	3/36	15/150	Motor Control Module Cooling Hoses and Pipes	3/36	15/150
Intake Manifold	3/36	15/150	Hybrid System Air Ducts	3/36	15/150
Mass Airflow Sensor	3/36	15/150	Hybrid System Relays	3/36	15/150
Intake Air Temperature Sensors	3/36	15/150	<b>Miscellaneous Parts</b> that are used in conjunction with the items in this list are covered. Some examples are clamps, brackets, piping, nuts, bolts, fasteners, switches, sensors, solenoids, wires, harnesses, connectors, seals, software updates, and gaskets.		
Intake Air Resonator	3/36	15/150	1 Coverage in years or 1,000 miles, whichever comes first.		
Air Cleaner Housing	3/36	15/150	2 Fuel filter replacement and fuel tank flushing are covered when contamination results from a defect in material or workmanship.		
Air Cleaner Housing Cover	3/36	15/150	3 Covered up to the first required replacement only; see the maintenance schedule in the owner's manual.		
Air Cleaner Element <sup>3</sup>	3/36	15/150			
Intake Air Ducts	3/36	15/150			