

# Federal and California Emissions Warranties Parts List

Emissions warranties are state specific. Refer to the years/miles<sup>1</sup> columns below as follows:

- A – Minimum coverage for all vehicles in all states.
- B – Vehicles that are registered and normally operated in California, Colorado, Connecticut, Delaware, Maine, Maryland, Massachusetts, New Jersey, New York, Oregon, Pennsylvania, Rhode Island, Vermont, and Washington.

System Covered/Part Name	A	B	System Covered/Part Name	A	B
<b>Crankcase Control System</b>			<b>Evaporative and Refueling Emissions Control System</b>		
Positive Crankcase Ventilation (PCV) Valve	3/36	<b>15/150</b>	Fuel Tank (including Vapor Control Valve and Vapor Recirculation Tube)	3/36	<b>15/150</b>
Engine Oil Fill Cap	3/36	<b>15/150</b>	Fuel Tank Pressure Sensor	3/36	<b>15/150</b>
<b>Exhaust Gas Recirculation (EGR) System</b>			Fuel Filter <sup>2</sup>	3/36	<b>15/150</b>
Exhaust Gas Recirculation (EGR) Valve (including EGR Valve Position Sensor)	3/36	<b>15/150</b>	Fuel Pressure Regulator	3/36	<b>15/150</b>
EGR Pipe	3/36	<b>15/150</b>	Fuel Level Sensor	3/36	<b>15/150</b>
EGR Cooler	3/36	<b>15/150</b>	Fuel Fill Pipe	3/36	<b>15/150</b>
<b>Exhaust System</b>			Fuel Fill Cap	3/36	<b>15/150</b>
Catalytic Converters	<b>8/80</b>	<b>15/150</b>	Fuel Lid Opener Switch	3/36	<b>15/150</b>
<b>Ignition System</b>			Fuel Lid Actuator	3/36	<b>15/150</b>
Ignition Coils	3/36	<b>15/150</b>	Evaporative Emission Canister	3/36	<b>15/150</b>
Spark Plugs <sup>3</sup>	3/36	<b>15/150</b>	Evaporative Emission Leak Check Assembly	3/36	<b>15/150</b>
Crankshaft Position Sensor	3/36	<b>15/150</b>	Evaporative Emission Lines and/or Hoses	3/36	<b>15/150</b>
Camshaft Position Sensors	3/36	<b>15/150</b>	Evaporative Emission Valves	3/36	<b>15/150</b>
<b>OBD System</b>			<b>Transmission Control System</b>		
Data Link Connector (DLC)	3/36	<b>15/150</b>	Transmission Fluid Temperature Sensor	3/36	<b>15/150</b>
Malfunction Indicator Lamp (MIL) Bulb	3/36	<b>15/150</b>			
CAN Gateway (including software updates)	3/36	<b>15/150</b>			

# Federal and California Emissions Warranties Parts List

---

System Covered/Part Name	A	B	System Covered/Part Name	A	B
<b>Fuel Injection System</b>					
Powertrain Control Module (including Barometric Pressure Sensor and software updates)	8/80	<b>15/150</b>	Air Cleaner Element <sup>3</sup>	3/36	<b>15/150</b>
Injectors	3/36	<b>15/150</b>	Air Cleaner Housing	3/36	<b>15/150</b>
Fuel Lines and/or Hoses	3/36	<b>15/150</b>	Air Cleaner Housing Cover	3/36	<b>15/150</b>
Fuel Rail	3/36	<b>15/150</b>	Intake Air Ducts	3/36	<b>15/150</b>
Electric Engine Coolant Pump	3/36	<b>15/150</b>	Intake Air Resonator	3/36	<b>15/150</b>
Engine Coolant Temperature Sensors	3/36	<b>15/150</b>	Intake Air Temperature Sensor	3/36	<b>15/150</b>
Knock Sensor	3/36	<b>15/150</b>	Intake Manifold	3/36	<b>15/150</b>
Manifold Absolute Pressure (MAP) Sensor	3/36	<b>15/150</b>	Mass Airflow Sensor	3/36	<b>15/150</b>
Oxygen Sensor	3/36	<b>15/150</b>	Throttle Body (including Throttle Position Sensor and Throttle Actuator)	3/36	<b>15/150</b>
Air Fuel Ratio Sensor	3/36	<b>15/150</b>			
Thermostat	3/36	<b>15/150</b>			
Accelerator Pedal Assembly	3/36	<b>15/150</b>			
<b>Valve Control System</b>					
Rocker Arm Oil Control Valve	3/36	<b>15/150</b>			
Rocker Arm Oil Pressure Switch/Sensor	3/36	<b>15/150</b>			
Variable Intake Valve Timing Control Actuator	3/36	<b>15/150</b>			
Electric Variable Valve Timing Control Motor	3/36	<b>15/150</b>			

# Federal and California Emissions Warranties Parts List

System Covered/Part Name	A	B	Miscellaneous Parts that are used in conjunction with the items in this list are covered. Some examples are clamps, brackets, piping, nuts, bolts, fasteners, switches, sensors, solenoids, wires, harnesses, connectors, seals, software updates, and gaskets.
<b>Hybrid System</b>			
Hybrid Battery Module	<b>8/100</b>	<b>10/150</b>	<sup>1</sup> Coverage in years or 1,000 miles, whichever comes first.
Battery Control Module (including Voltage Sensors and software updates)	<b>8/100</b>	<b>15/150</b>	<sup>2</sup> Fuel filter replacement and fuel tank flushing are covered when contamination results from a defect in material or workmanship.
Drive Motor Control Module (including software updates)	<b>8/100</b>	<b>15/150</b>	<sup>3</sup> Covered up to the first required replacement only; see the maintenance schedule in the owner's manual.
Drive Motor/Generator Stators and Rotors (including internal Position Sensors and Temperature Sensor)	<b>8/100</b>	<b>15/150</b>	
High Voltage Power Cables	<b>8/100</b>	<b>15/150</b>	
Battery Module Fan	3/36	<b>15/150</b>	
Battery Module Temperature Sensors	3/36	<b>15/150</b>	
Battery Current Sensor	3/36	<b>15/150</b>	
Busbars	3/36	<b>15/150</b>	
Electronics Coolant Pump	3/36	<b>15/150</b>	
High Voltage and Bypass Contactors and Fuse	3/36	<b>15/150</b>	
Hybrid Battery Service Connector	3/36	<b>15/150</b>	
Motor Control Module Coolant Radiator	3/36	<b>15/150</b>	
Motor Control Module Coolant Expansion Tank	3/36	<b>15/150</b>	
Motor Control Module Cooling Hoses and Pipes	3/36	<b>15/150</b>	
Hybrid System Relays	3/36	<b>15/150</b>	
Intelligent Power Unit Air Ducts	3/36	<b>15/150</b>	