Federal and California Emissions Warranties Parts List

All emissions-related components are covered for a minimum of 3 years or 36,000 miles, whichever comes first. The components listed, depending on location, receive extended coverage. Federal warranty coverage applies to all vehicles registered and normally operated in all states other than California, Connecticut, Massachusetts, Maine, New Jersey, Oregon, Pennsylvania, Rhode Island, Vermont, or Washington. The OR/PA column applies to all vehicles registered and normally operated in Oregon or Pennsylvania. PZEV warranty coverage applies to all vehicles with PZEV emissions certification that are registered and normally operated in California, Connecticut, Massachusetts, Maine, New Jersey, New York, Rhode Island, and Vermont. Refer to the under-hood tune-up label to see if your vehicle has PZEV emissions certification If you're still not sure if your vehicle has PZEV emissions certification, or if you want to obtain an updated list, contact your authorized Honda dealer, Honda Customer Service (see inside front cover), or go online to www.honda.com.

System Covered/Part Name	FED (40 States)	OR/PA	PZEV (CA/CT/MA/ ME/NJ/NY/ RI/VT)	System Covered/Part Name	FED (40 States)	OR/PA	PZEV (CA/CT/MA/ ME/NJ/NY/ RI/VT)
Crankcase Control System Positive Crankcase Ventilation (PCV) Valve Engine Oil Fill Cap	3/36 3/36	3/50 3/50	15/150 15/150	Exhaust System Catalytic Converters Ignition System Ignition Coils	8/80 3/36	8/80 3/50	15/150 15/150
Evaporative and Refueling Emission Control System Fuel Tank (including Fuel Tank Vapor Recirculation Tube) Fuel Tank Pressure Sensor	3/36 3/36	3/50 3/50	15/150 15/150	Spark Plugs Crankshaft Position Sensor Camshaft Position Sensor Fuel Injection System	3/36 3/36 3/36	3/50 3/50 3/50	15/150 15/150 15/150
Fuel Pressure Regulator Fuel Filter (including Fuel Tank Vapor/ Liquid Separation and Vapor Contro Valves)*1 Fuel Fill Pipe Fuel Fill Cap Evaporative Emissions Lines and/or Hoses Evaporative Emissions Canister Evaporative Emissions Valves	3/36 3/36 3/36 3/36 3/36 3/36 3/36	3/50 3/50 3/50 3/50 3/50 3/50 3/50	15/150 15/150 15/150 15/150 15/150 15/150	Engine/Powertrain Control Module (including Barometric Pressure Sensor and Software Upgrades) Injectors Fuel Rail Fuel Lines and/or Hoses Knock Sensors Oxygen Sensors Air Fuel Ratio Sensor MAP Sensor	8/80 3/36 3/36 3/36 3/36 3/36 3/36 3/36	8/80 3/50 3/50 3/50 3/50 3/50 3/50 3/50	15/150 15/150 15/150 15/150 15/150 15/150 15/150
Exhaust Gas Recirculation (EGR) System Exhaust Gas Recirculation (EGR) Valve (including EGR Valve Position Senso		3/50	15/150	Engine Coolant Temperature Sensor Thermostat Accelerator Pedal Module (including Pedal Position Sensors)	3/36 3/36 3/36	3/50 3/50 3/50	15/150 15/150 15/150

2009 Civic Hybrid APL 39985 (0808)

Federal and California Emissions Warranties Parts List

System Covered/Part Name	FED (40 States)	OR/PA	PZEV (CA/CT/MA/ ME/NJ/NY/ RI/VT)
OBD System Malfunction Indicator Lamp (MIL) Data Link Connector (DLC)	3/36 3/36	3/50 7/70	15/150 15/150
Transmission Control System CVT Speed Sensors CVT Pressure Control Valves/Valve Boo Transmission Range Switch	3/36 dy 3/36 3/36	3/50 7/70 3/50	15/150 15/150 15/150
Intake Air System Throttle Body (including Throttle Position Sensor and Throttle Actuator) Mass Airflow Sensor Intake Manifold Assembly Intake Air Resonator Intake Air Ducts Air Cleaner Housing Air Cleaner Housing Cover Air Cleaner Element '2	3/36 3/36 3/36 3/36 3/36 3/36 3/36 3/36	7/70 3/50 7/70 3/50 3/50 3/50 3/50 3/50	15/150 15/150 15/150 15/150 15/150 15/150 15/150
Valve Control System Rocker Arm Control Valve Assembly Rocker Arm Control Oil Pressure Switch Engine Oil Pressure Sensor	3/36 n 3/36 3/36	7/70 3/50 3/50	15/150 15/150 15/150
Integrated Motor Assist System (IMA Battery Assembly (including all internal components) DC-DC Convertor	8/80 8/80	8/80 8/80	10/150 15/150

System Covered/Part Name	FED (40 States)	OR/PA	PZEV (CA/CT/MA/ ME/NJ/NY/ RI/VT)
Integrated Motor Assist System (IMA))		RI/VI)
(Cont.) Motor Control Module (including Motor Power Invertor Module, Voltage Convertor Module, and Motor Curren	t		
Sensor)	8/80	8/80	15/150
Battery Condition Monitor Module	8/80	8/80	15/150
Motor Rotor	8/80	8/80	15/150
Motor Stator	8/80	8/80	15/150
Bus Bar	3/36	3/50	15/150
Motor Control Module Relay	3/36	3/50	15/150
Motor Commutation Sensor	3/36	7/70	15/150
Motor Rotor Position Sensor	3/36	3/50	15/150
Motor Power Cable	3/36	7/70	15/150
High Voltage Motor Power Inverter Module Cable	3/36	3/50	15/150
Motor Power Inverter Module/Battery Module Fan Assembly (including Air Ducts)	3/36	3/50	15/150
High Speed Motor Power Inverter Modu Fan Control Relay	le 3/36	3/50	15/150

Miscellaneous Parts that are used in conjunction with the items in this list are covered. Some examples are clamps, brackets, piping, nuts, bolts, fasteners, switches, sensors, solenoids, wires, harnesses, connectors, seals, and gaskets.

^{*1} Fuel filter replacement and fuel tank flushing are covered when contamination results from a defect in material or workmanship.

^{*2} Covered up to the first required replacement only; see the maintenance schedule in the owner's manual.