- Latest Call History: Set whether the history shortcut is displayed in the phone screen.
- Auto Sync Phone: Set phonebook and call history data to be automatically imported when a
  phone is paired to HFL.
- Auto Phone Call Transfer: Set calls to automatically transfer from your phone to HFL when
  you enter the vehicle.
- Ringtone: Select a fixed ringtone or the one from the connected cell phone.

# **Customized Features**

Use the audio/information screen to customize certain features.



When you customize settings:

- Make sure that the vehicle is at a complete stop.
- Put the transmission into P.

# **How to Customize the General Settings**

With the power mode in ON, select  $\P$  (Home) icon  $\Rightarrow$  General Settings  $\Rightarrow$  setting item.

# **List of Customizable Options**

### System

#### Date & Time → Set Date & Time

#### **Automatic Date & Time**

On\*1/Off

#### **Set Date**

Adjusts date.

Q Adjusting the Clock ▶P.212

#### **Set Time**

Adjusts clock.

O Adjusting the Clock ►P.212

#### Date & Time → Time Zone

#### **Automatic Time Zone**

On\*1/Off

#### (Select time zone)

Changes the time zone manually.

# Date & Time → Auto Daylight Saving Time

On\*1/Off

#### Date & Time → Date Format

Day-of-week, MM DD, YYYY<sup>\*1</sup>/ YYYY.MM.DD Day-of-week/ YYYY.MM.DD (Day-of-week)/Day-ofweek DD.MM.YYYY/DD.MM.YYYY

#### Date & Time → Time Format

12H\*1/24H

### Language

### English (United States)\*1/Español/ Français

#### **Touch Panel Sensitivity**

Low\*1/High

#### About → IP Address

Displays the Android setting items.

#### About → Wi-Fi MAC Address

Displays the Android setting items.

#### **About** → **Bluetooth MAC Address**

Displays the Android setting items.

#### About → Serial Number

Displays the Android setting items.

#### About → Up Time

Displays the Android setting items.

### **Connections**

# Manage Device Connections → Options

# Bluetooth

On\*1/Off

#### **Priority Device Information**

Displays the priority device.

#### **Change Name**

Changes vehicle name for *Bluetooth*® connection setting.

# **Smartphone Projection Screen Size**

Normal/Wide\*1

#### **Smartphone Projection Error Code**

Displays the error codes of the smartphone projection.

#### About → Model Number

Displays the Android setting items.

#### About → Android Version

Displays the Android setting items.

#### **About** → Kernel Version

Displays the Android setting items.

#### **About** → **Build Number**

Displays the Android setting items.

#### **About** → **Software Version**

Displays the Android setting items.

#### Factory Data Reset

#### Cancel/Continue

\*1: Default Setting.

# Manage Device Connections → + Connect New Device

Pairs a new phone to HFL.

O About Wireless Connections
P.205

# Manage Device Connections → (Saved Devices)

Connects, disconnects, or deletes a paired phone.

O About Wireless Connections
P.205

#### Wi-Fi → Options

#### Wi-Fi

On\*1/Off

#### **Add Network**

Allows you to connect to a new external network.

#### **Saved Networks**

Delete a saved network or change update permission settings for the selected network.

#### Wi-Fi → (Detected Networks)

Displays the detected network(s).

# Access Point → Options

#### **Access Point**

On/Off\*1

# Privacy

## Data Sharing with Honda

Disable/Enable\*1

### Microphone

#### Use microphone

On\*1/Off

#### Recently accessed

Displays recent apps that accessed the microphone.

#### Manage microphone permissions

Displays the microphone permissions.

#### Location

Sets the data sharing permission for each function.

#### App permissions

Sets the data sharing permission for each function

#### **Edit Access Point Settings**

This screen allows you to change the security settings and password.

# Data Connection Options → Set Up Wi-Fi

Sets personal hotspot (phone tethering).

Q Wi-Fi Connection ►P.222

# Data Connection Options → Set Up Vehicle Data Plan

Sets AT&T vehicle data plan.

Q AT&T Hotspot ►P.224

\*1: Default Setting.

### System-wide Permission Settings

Sets the data sharing permission for each function

#### Infotainment system data

Sets the data sharing permission for each function.

# Data sharing with Google\*2

Sets the data sharing permission for each function.

#### Ads

Sets the data sharing permission for each function.

# Google legal\*<sup>2</sup> → Google Terms of Service\*<sup>2</sup>

Displays the Google URL.

# Google legal\*² → Google Privacy Policy\*²

Displays the Google URL.

- \*1: Default Setting.
- \*2: Please confirm the details on the audio/ information screen. Specifications are

subject to change via system updates, etc.

# Display

#### **Brightness**

Changes the brightness of the audio/information screen.

#### **Contrast**

Changes the contrast of the audio/information screen.

#### **Black Level**

Changes the black level of the audio/information screen.

### Sound

# Bass / Mid / Treble

#### Treble

Adjusts the settings of the audio speakers' sound.

O Adjusting the Sound ▶P.213

#### Midrange

Adjusts the settings of the audio speakers' sound.

Q Adjusting the Sound ►P.213

#### Bass

Adjusts the settings of the audio speakers' sound.

O Adjusting the Sound ▶P.213

#### **Bose Centerpoint\***

Adjusts the settings of the audio speakers' sound.

O Adjusting the Sound ▶P.213

# Day Mode\*1

Changes to the daytime mode.

#### Night Mode\*1

Changes to the night mode.

#### **Display Off**

Turns the audio/information screen brightness off.

\*1: When the AID sensor is disabled.

# Audio Zones & Balance / Fader\*

Adjusts the settings of the audio speakers' sound.

O Adjusting the Sound ►P.213

# Bose Dynamic Speed Compensation\*

Adjusts the settings of the audio speakers' sound.

O Adjusting the Sound ►P.213

#### Balance / Fader\*

Adjusts the settings of the audio speakers' sound.

Q Adjusting the Sound ▶P.213

#### **Speed Volume Compensation\***

Adjusts the settings of the audio speakers' sound.

O Adjusting the Sound ►P.213

<sup>\*:</sup> Not available on all models

# Sound Volume

#### **System Sounds**

0~2\*1~3

#### **Voice Recognition**

1~2\*1~11

#### **Navigation Guidance**

0~6\*1~11

## Camera

# Rear Wide Camera\* → Guidelines

#### **Fixed Guideline**

On\*1/Off

#### **Dynamic Guideline**

On\*1/Off

#### Multi View Camera\* → Guidelines

#### **Fixed Guideline**

On\*1/Off

#### **Dynamic Guideline**

On\*1/Off

#### Voice Control

#### Default Assist App

None/Alexa/Google Assistant\*1

# Listen for "Hey Siri"\*2

On/Off\*3

#### **Google Assistant**

Sets the functions of Google Assistant.

0~20\*1~40

\*1: Default Setting.

# Multi View Camera\* → Customize

#### **Show after Shifting from Reverse**

On/Off\*1

# Auto Display When Obstacle is Detected

On\*1/Off

#### **Cross Traffic Monitor**

On\*1/Off

\*1: Default Setting.

**Phone Calls** 

<sup>\*1:</sup> Default Setting.

<sup>\*2:</sup> Activates when the iPhone is connected.

<sup>\*3:</sup> Default Setting (when Apple CarPlay is launched, the setting will be switched to **On**).

<sup>\*:</sup> Not available on all models

# Security

You can customize security settings. Please confirm the details on the audio/information screen. Specifications are subject to change via system updates, etc.

# Google


You can customize Google settings. Please confirm the details on the audio/information screen. Specifications are subject to change via system updates, etc.

# Advanced Settings

You can customize advanced system settings. Please confirm the details on the audio/information screen. Specifications may be changed via system updates, etc.

# **How to Customize the Vehicle Settings**

With the power mode in ON, select  $\P$  (Home) icon  $\rightarrow$  Vehicle Settings  $\rightarrow$  setting item.



- 1 Change View Icon
- 2 Menu Icon
- **3**D vehicle image
- You can change vehicle image by selecting Change View.
- You can change the color of the vehicle image by selecting the **Menu**.

O, Vehicle Color Settings ►P.247

# **List of Customizable Options**

# Driver Assist System Setup Forward Collision Warning Distance

Long/Normal\*1/Short

ACC Forward Vehicle Detect Beep

**Road Departure Mitigation Setting** 

Narrow/Normal\*1/Wide/Warning Only

**Lane Keeping Assist Suspend Beep** 

On/Off\*1

On/Off\*1

**Blind Spot Information** 

Audible And Visual Alert\*1/Visual Alert

Traffic Sign Recognition System Display Setting

On\*1/Off

Traffic Sign Recognition System Speed Limit Warning

On/Off\*1

Meter Setup

Adjust Outside Temp. Display

-5°F ~ ±0°F\*1 ~ +5°F (U.S.)

-3°C ~ ±0°C\*1 ~ +3°C (Canada)

"Trip A" Reset Timing

When Fully Refueled/IGN Off/ Manually Reset<sup>\*1</sup>

"Trip B" Reset Timing

When Fully Refueled/IGN Off/ Manually Reset<sup>\*1</sup>

**Adjust Alarm Volume** 

High/Mid\*1/Low

**Reverse Alert Tone** 

On\*1/Off

#### Speed Limit Warning Threshold Setting

Speed Limit \*1/Speed Limit +3mph/ Speed Limit +5mph/Speed Limit +10mph (When mph is selected)

Speed Limit\*1/Speed Limit +5km/h/ Speed Limit +10km/h/Speed Limit +15km/h (When km/h is selected)

**Driver Attention Monitor** 

Tactile And Audible Alert\*1/Tactile Alert/Off

**Rear Sensor Setting** 

On\*1/Off

\*1: Default Setting.

#### **Fuel Efficiency Backlight**

On\*1/Off

Turn by Turn Auto Display

On\*1/Off

**Rear Seat Reminder** 

On\*1/Off

Speed/Distance Units

km/h ⋅ km/mph ⋅ miles\*1 (U.S.)

**km/h · km**<sup>\*1</sup>/**mph · miles** (Canada)

\*1: Default Setting.

# **■** Driving Position Setup

#### **Memory Position Link**

On\*1/Off

# Keyless Access Setup

**Door Unlock Mode** 

Driver Door Only\*1/All Doors

#### **Keyless Access Light Flash**

On\*1/Off

#### **Keyless Access Beep**

On\*1/Off

# Lighting Setup

**Auto High-Beam** 

On\*1/Off

#### **Interior Light Dimming Time**

60sec/30sec\*1/15sec

#### **Headlight Auto Off Timer**

60sec/30sec/15sec\*1/0sec

#### **Door Setup**

**Auto Door Lock** 

# With Vehicle Speed\*1/Shift From P/

#### **Auto Door Unlock**

All Doors When Driver's Door Opens\*1/All Doors With Shift To P/All Doors with IGN Off/Off

#### **Walk Away Auto Lock**

On/Off\*1

#### **Keyless Lock Answer Back**

On\*1/Off

#### Power Tailgate Setup

**Keyless Open Mode** 

Anytime\*1/When Unlocked

#### Seat Position Movement At Entry/ Exit

On\*1/Off

\*1: Default Setting.

#### Remote Start System On/Off

On\*1/Off

#### **Lockout Prevention**

On\*1/Off

\*1: Default Setting.

#### **Auto Light Sensitivity\***

Max/High/Mid\*1/Low/Min

#### **Auto Headlight On with Wiper On**

On\*1/Off

\*1: Default Setting.

#### **Security Relock Timer**

30sec\*1/60sec/90sec

#### **Auto Folding Door Mirror\***

On\*1/Off

# Keyless Remote Power Window Control

On\*1/Off

#### **Lock Presetting**

On\*1/Off

\*1: Default Setting.

#### **Power Open By Outer Handle**

OFF (Manual Only)/ON (Power/ Manual)\*1

<sup>\*:</sup> Not available on all models

#### Hands Free Access Function\*

On\*1/Off

Climate Control Setup

Driver Seat automatic Climate Control

On\*1/Off

Passenger Seat automatic Climate Control

On\*1/Off

\*1: Default Setting.

\*1: Default Setting.


## Maintenance Info.

Maintenance Info.

**Select Reset Items** 

# **Vehicle Color Settings**

You can change the body color of the vehicle image on the vehicle settings screen.



# 1 Color

- [1] Select Menu.
- [2] Select Body Color.
- [3] Select desired color.

# **How to Customize the Profile Settings**

# Change Profile

You can change and add users.

O, User Information ►P.232

<sup>\*:</sup> Not available on all models

# Manage Profile

Use **Manage Profile** to change profile settings. Please confirm the details on the audio/information screen.

Specifications are subject to change via system updates, etc.

### Driving Position Setting

By adjusting the seating position and then pressing the Memory 1 or Memory 2 button, you can store or recall up to 2 driving positions per user.

O Driving Position Memory System ►P.70

Refer to the following for details on how to adjust seating position.

Q Adjusting the Front Seat Positions ▶P.66

# **Defaulting All the Settings**

Reset all the menu and customized settings to their factory defaults.

- If you perform Factory Data Reset, it will reset the preinstalled apps to their factory default.
- If you perform **Factory Data Reset**, you cannot use the HondaLink® because it goes offline.





When you transfer the vehicle to a third-party, reset all settings to default and delete all personal data.

# Defaulting General Settings

Only the Owner user can execute.

If you are not the Owner user, please switch users.

# O Switching Users ►P.233

- [1] Select (Home) icon.
- [2] Select **General Settings**.
- [3] Select System.
- [4] Select Factory Data Reset.
  - » A confirmation message appears on the screen.
- [5] Select **Continue** to reset the settings.
- [6] Select Continue again to reset the settings.
  - » The system will reboot.

# Defaulting Vehicle Settings

- [1] Select (Home) icon.
- [2] Select Vehicle Settings.
- [3] Select Menu.
- [4] Select Default All.
- [5] Select Yes.