


Bluetooth® HandsFreeLink® (if equipped)

Pairing Your Phone

Press and release the HFL Talk button before you give a command.



Making a Call

1. **Press** the HFL Talk button.



2. **Say** "Call" or "Dial" and the desired phone number.



3. **Press** the HFL Talk button, and **say** "Call" or "Dial" to continue.



4. The call is connected and heard through the vehicle's speakers.



Receiving a Call

1. A notification is heard and the incoming phone number appears on the audio display.



2. **Press** the HFL Talk button to accept the call.



3. **Press** the HFL Back button to end or decline the call.

