NAVIGATION (if equipped)

Entering a Destination Using Voice Commands

Set a destination using a street address. For other destination options, see your Navigation Manual.

Press and release the Navi Talk button before you give a command.

1. Say "Display menu." Say "Address."



 Say "Street," then say the street name on the next screen. Do not include the direction (N, S, E, W) or type (St., Ave., Blvd., etc.).



3. A list of street names appears. Say the number next to the street you want to select.

Select	a street:	CHANNER TO SHELL MOOR
	MAHEE	1000
- 2	MALAHINE	100000000000000000000000000000000000000
0	MAYDON	
	MATIN	Contraction of the local division of the loc
DOM: B	MAIN	
	MAINE	Concession in which the real of the local division in which the real of the local division is not the local division of the local division in the local division in the local division is not the local division of the local division in the local dinted dinter division in the local divisi



DELETE

567890

4. **Say** the entire street address



Sa	we address appears in more than	
100 1	VENICE	13mi 🛓
-	LOS ANGELES	15mi #
\bigcirc	ALHAMBRA	20mi #
- ·	HUNTINGTON BEACH	21mi N
DOBH S	BURBANK	23mi #

6. The system displays the "Calculate route to" screen. **Say** "*OK*" to set the route.



Real-time navigation system uses GPS and a map database to show your current location and help guide you to a desired destination.

Using the Find Nearest Command

Find a nearby point of interest, such as a gas station, movie theater, restaurant, etc.

Press and release the Navi Talk button before you give a command.

 From the map screen, say "Find nearest ATM."



2. A list of the nearest ATMs in your area is displayed by shortest distance to destination.



3. **Say** the number next to the destination you want to select.



4. The system displays the "Calculate route to" screen. **Say** "OK" to set the route.

PILOT BANK 1234 PILOT BLVD ANAHEIM, CA	By Direct Rout
18 Address Book	View Routes View Dest, Map

Map Screen Legend

