

PADDLE SHIFTING* (if equipped)

Manually shift your vehicle's gears up or down. Useful for engine braking or when driving in hilly terrain or cornering.

Paddle Modes

Pull (-) to shift down.




Pull (+) to shift up.




D-Paddle Shift Mode

- **Move** the shift lever to the D position.
- **Pull (+) or (-)** to shift to a higher or lower gear.
- The selected gear number is displayed on the gear position indicator.
- When the vehicle's speed is constant or when you press the accelerator pedal, the mode returns to automatic.



Sequential Shift Mode

- **Move** the shift lever to the S position.
- **Pull (+) or (-)** to manually shift between first and fifth gears.
- The M indicator and selected gear number are displayed on the gear position indicator.
- **Move** the shift lever to the D position to cancel this mode.



**V6 automatic transmission model only*