


INTELLIGENT MULTI-INFORMATION DISPLAY (i-MID)

Accessing the MID



Press the INFO button to change main displays.



Main Displays

Main display



Power flow monitor



Clock
(or wallpaper)



Ecological
Drive
Display



Audio display
(or Phone
display during
call)



Trip
computer




A warning or indicator message may appear as necessary. **Press** the INFO button to clear it.



Consists of several displays that provide you with useful information.

Sub-displays



Press the SEL/RESET button to change sub-displays.



Outside
temperature
Odometer
Trip A
Trip B
Clock

Steering Wheel Controls



(+) Button:


Press to scroll upward.

(◀) Button:

Press to go back to the previous display.

(-) Button:

Press to scroll downward.



Display/Information Button:

Change main displays.

SOURCE Button:

Press to enter your selection.

(▶) Button:

Press to go to the next display.

MENU Button:

Press to go to Vehicle Menu for customization and other settings.