
BASIC AUDIO OPERATION

Operate basic controls of your audio system using various convenient methods.

Steering Wheel Controls



Audio Panel Controls

Audio sources: Select FM/AM, CD, or AUX.

Selector knob: – Rotate and press to make and enter selections.

BACK button: Return to the previous display or cancel a selection.



Skip/Seek buttons: Change stations or tracks.

MENU button: Select options for the selected audio source.

USB Connection





Connect an iPhone or iPod cable or a USB flash drive to the USB port in the front console.

Connect your device only when your vehicle is stopped.

iPod[®] OR USB FLASH DRIVE

Play audio files from your compatible iPod or USB flash drive through your vehicle's audio system.

Playing Audio Files

- I. Connect the iPod cable or USB flash drive to the USB port in the front console.
- 2. Press SOURCE or AUX until iPod or USB appears.
- 3. Press the SKIP buttons to change tracks.



iPod is a trademark of Apple, Inc.

Searching for Music

I. Press MENU. Use the selector knob to make and enter selections.



- 2. Select Music Search.
- 3. Select a category or folder.
- 4. Select a track to begin playing.

BLUETOOTH R AUDIO

Play stored or streaming audio from your compatible phone through your vehicle's audio system. Visit *handsfreelink.honda.com* to check if this feature is compatible with your phone.

Playing Bluetooth Audio

- I. Make sure your phone is on and paired to *Bluetooth*[®] HandsFreeLink[®].
- 2. Press SOURCE or AUX until *Bluetooth* Audio appears.
- 3. From your phone, open the desired audio player or app and begin playing. Sound is redirected to the audio system. Make sure the volume on your phone is properly adjusted.
- 4. Press the SKIP buttons to change tracks.



Notes:

- You may need to enable additional Bluetooth settings on your phone for playback.
- The play/pause function and remote audio controls are not supported on all phones.

